



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1655	7333A24	GEAR HOUSING ASSY, COMP. (L)	1	
-	1655	7333A26	GEAR HOUSING ASSY, COMP. (E)	1	
1	1655	7333A23	GEAR HOUSING ASSY	1	
1A	22	85822A 1	CONNECTOR ASSEMBLY, SP	1	
2	17	46912	DOWEL PIN, GEAR HOUSING	2	
3	16	57921	STUD, GEAR HOUSING TO D	1	
4	16	57920	STUD, GEAR HOUSING TO D	2	
5	16	56297	STUD, WATER PUMP BASE A	1	
6	16	30667	STUD, WATER PUMP BASE A	2	
7	31	32898	BEARING, ROLLER - DRIVE S	1	
8	45	76036	DRIVE SHAFT (LONG SHAFT)	1	
8	45	77159	DRIVE SHAFT (EXTRA LONG SI	1	
9	43	68548	GEAR, PINION - DRIVE SHAFT	1	
10	11	35921	NUT, PINION GEAR TO DRIVE :	1	
11	23	70412	SPACER, BALL BEARING TO B	1	
11	15	57007A 1	SHIM, BALL BEARING TO BASE	AR	4
12	31	69220	ROLLER BEARING, DRIVE SHA	1	
14	27	33146	GASKET, WATER PUMP BASE	1	6
15	25	33145	"O" RING, WATER PUMP BASE	1	6
16	46	73804A 1	WATER PUMP BASE ASSEMBL	1	
17	26	31489	OIL SEAL, WATER PUMP BAS	1	
18	26	31507	OIL SEAL, WATER PUMP BAS	1	
19	17	35973	DOWEL PIN	2	WATER PUMP BASE TO WATE
20	27	32433	GASKET	1	LOWER - WATER PUMMP BASE 6
21		32435	PLATE, FACE	1	WATER PUMP TO WATER PUM
22	27	32434	GASKET, UPPER	1	FACE PLATE TO WATER PUM 6
23	46	64141A 1	WATER PUMP BODY ASSEMBL	1	
24		48752	INSERT, WATER PUMP BOD	1	
26	26	38970	SEAL, RUBBER - WATER INLI	1	
27	47	65960	IMPELLER, WATER PUMP	1	
28	28	56654	KEY, IMPEELER DRIVE	1	
29	10	30720	SCREW	1	WATER PUMP BODY TO GEAR
30	13	26992	LOCKWASHER, WATER PUMP	1	
31	12	29245	WASHER	3	WATER PUMP BODY FASTENIN
32	11	35888	NUT, WATER PUMP FASTENING	2	
33	12	36001	WASHER, WATER PUMP BOD	1	
34	11	35814	NUT, WATER PUMP BODY FAS	1	
35	25	30271	RING, RUBBER - CENTRIFUGAI	1	(DRIVE SHAFT) 6
36	23	29804	SLEEVE, GUIDE - WATER INLE	1	
37		37641	SEAL, EXHAUST ELBOW	1	
38		28051	PLATE, SUPPORT - EXHAUST	1	