



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
28	91	74951	SPANNER WRENCH	1		
29		NSS	NOT SOLD SEPARATE, Lock-Ring	1	(SNAP-ON SRP-4)	
30		NSS	NOT SOLD SEPARATE, Expanding	1	(SNAP-ON CG41-11)	
31		NSS	NOT SOLD SEPARATE, Collet	1	(SNAP-ONG CG41-12)	
32	91	63209	HEAT LAMP	1		
33	91	12349A 2	LOCATION TOOL, Pinion	1	SN# 0T979999 & Below	
33	91	12349A05	TOOL, Pinion Locating	1	SN# 0T980000 & Up	
34	91	13945	INSTALLATION TOOL, Bearing	1		
35	91	13949	DRIVER, Oil Seal	1		
36	91	14308T02	BEARING RACE TOOL	1		
37	91	14309T02	INSTALLATION TOOL, Bearing	1		
38	91	14310T 1	WEAR SLEEVE INSTALLATION T	1		
39	91	14311A 2	PRE LOAD TOOL, Bearing	1	SN# 0T979999 & Below	
39	91	14311A04	TOOL, Preload	1	SN# 0T980000 & Up	
40	91	15755T	MANDREL	1		
41	91	19660	INDICATOR TOOL, Backlash	1		
42	91	31106T	MANDREL, Bearing Driver Cup	1		
43	91	31108T	DRIVER, Oil Seal	1		
44	91	36569T	DRIVEHEAD TOOL	1		
45	91	804776A 1	DRIVESHAFT HOLDING TOOL	1		
46	91	31229	SHAFT	1		
47	11	24156	NUT, (.625-18)	1		
48	91	34569A 1	PULLER ASSEMBLY, Slide Hamme	1		
49	91	37323	DRIVER ROD	1		
50	91	37241	PULLER PLATE	1		
51	91	37350T	MANDREL	1		
52	91	46086A 1	PULLER JAW ASSEMBLY	1		
53	91	58222A 1	DIAL INDICATOR TOOL	1		
54	91	78473	INDICATOR TOOL, Backlash	1		
55	91	85716	PULLER BOLT	1		
56	91	83155	ADAPTER KIT, Dial Indicator	1		
57	91	83165T	PULLER ASSEMBLY	1		
58	91	856875A 1	BEARING INSTALLATION TOOL	1		
59	91	877321A 1	BEARING INSTALLATION TOOL	1		
-	91	880177	SCRENCH, (10mm), 10 MM	1		
-	91	881828	STARBIT TOOL KIT	1		