



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		66530A	FUEL PUMP ASSEMBLY	1	
2	21	30430A	CHECK VALVE ASSEMBLY	1	
3		66599A	DIAPHRAGM ASSEMBLY	1	6
4			GASKET, DIAPHRAGM	2	6
5			GASKET, CHECK VALVE	2	6
6			"O" RING, COVER TO HOUS	1	6
7			GASKET, NYLON-FILTER CO	1	6
8	35	59072	SCREEN, FILTER-INLET	1	6
9		23004	RETAINER, CHECK VALVE	1	
10	10	20037	SCREW, RETAINER TO FUEL F	2	
12		59071	COVER, FUEL INLET	1	
13	10	37370	SCREW, COVER TO FUEL PUM	1	
14	22	64704	FITTING, FUEL OUTLET	1	
15	10	66686	SCREW, FUEL PUMP TO BASE	2	
16		66575	BASE, FUEL PUMP	1	
17	10	66687	SCREW, FUEL PUMP TO BOTTO	3	
18	22	64704	FITTING, PULSE LINE (90 DEG.)	2	
19	24	68434	SPRING, PLUSE LINE	2	
20	32	70732	PULSE LINE (3 1/4")	2	
21	54	68424	CLAMP, FUEL LINE ATTACHING	12	
22	22	64704	FITTING, PULSE LINE TO TRANS	2	
23	32	70432	FUEL LINE, ADAPTOR TO FUEL F	1	
24	22	63981	ELBOW, FUEL LINE TO ADAPTOR	1	
25	32	70432	FUEL LINE	1	FUEL PUMP TO UPPER CARBU
26	54	22627	CLIP, FUEL LINE ATTACHING	1	
27	10	62568	SCREW, FUEL LINE CLIP (3/8")	1	
28		69205	"D" WASHER, FUEL LINE CLIP SI	1	
29	22	66328	FITTING, TEE-UPPER CARBURE	1	
30	22	64706	FITTING, TEE-CENTER CARBURE	1	
31	22	64704	FITTING, ELBOW-LOWER CARBL	1	
32	32	70432	FUEL LINE, CARBURETOR TO C/	2	
33		22833	ADAPTOR, CHECK UNIT (FUEL LI	1	
34		23069	STEM, CHECK UNIT ADAPTOR	1	
35	24	23067	SPRING, ADAPTOR STEM	1	
36	25	20415	"O" RING, ADAPTOR STEM	1	6
37		30188	CUP WASHER, ADAPTOR	1	
38	10	69029	SCREW, ADAPTOR TO BOTTOM	2	
-	27	60476A75	GASKET SET		