



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1440	3291A 1	CLAMP BRACKET ASSEMBLY	2		
2		28403A 3	THUMB SCREW ASSEMBLY	2		
3	12	28404	WASHER, THUMB SCREW	2		
4		30664	TUBE, TILT - CLAMP BRACKET T	1		
5	12	52864	WASHER, CLMAP BRACKET TILT	2		
6	11	56041	NUT, TILT TUBE FASTENING	2		
7		53078	CAP, PLASTIC - TILT TUBE	2		
8	23	59624	SPACER, CLAMP BRACKET STUC	1		
9	16	59625	STUD, CLAMP BRACKET	1	(NOT USED WITH FULL POWER)	
10	13	26993	LOCKWASHER, CLAMP BRACKET	2		
11	11	28770	NUT, CLAMP BRACKET STUD	2		
12	17	49930A 1	TILT LOCK PIN ASSEMBLY	1		
14	1453	4886A 4	SWIVEL BRACKET ASSEMBLY (S	1		
14	1447	4885A 4	SWIVEL BRACKET ASSEMBLY (L	1		
15	26	37448	OIL SEAL, SWIVEL BRACKET	2		
16	10	47828	SCREW, DRIVE - SWIVEL BRAC	1		
17	22	23612	FITTING, GREASE - SWIVEL BF	1		
18		29359	LUBRICAP, SWIVEL BRACKET I	1		
19		47799A 1	TILT LOCK ASSEMBLY, STARB	1		
20		47800A 1	TILT LOCK ASSEMBLY, PORT	1		
21		47802	TUBE, TILT LOCK	2		
22	18	47959	COTTER PIN, TILT LOCK TUBE	2		
23	23	47803	BUSHING, TILT LOCK TUBE	2		
24	13	24850	WASHER, WAVE - TILT LOCK T	1		
25	24	28659	SPRING, COIL - SWIVEL BRACKE	1	(NOT USED WITH FULL POWER)	
26	17	38311	PIN, COIL SPRING MOUNTING	2	(NOT USED WITH FULL POWER)	
27	17	49841A 1	SWIVEL PIN AND STEERING ARM	1		
27	17	49840A 1	SWIVEL PIN AND STEERING ARM	1		
28		28203	BUMPER, STEERING ARM	1		
29	10	49554	BOLT, STEERING ARM TO UPPE	2		
30	11	34933	NUT, STEERING ARM BOLT FAS	2		
31	10	31830	SCREW, RIDE-GUIDE ATTACHIN	1		
32	11	20509	NUT, RIDE-GUIDE ATTACHING S	1		
33	12	37429	WASHER, SWIVEL PIN - LOWER	1		
34		37419	YOKE, BOTTOM	1		
35	11	37424	NUT, SWIVEL PIN RETAINING	1		
36		28205	STRAP STOP, DRIVE SHAFT HOL	1		
37	10	28200	SCREW, STRAP STOP TO DRIVE	1		
38	11	25269	NUT, STRAP STOP FASTENING	1		
39	23	28688	SPACER, RUBBER - COIL SPRING	2		
40	55	28416	PIN, UPPER SHOCK MOUNTING	1		