



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	436	4842A 3	CRANKSHAFT ASSEMBLY	1		
2	11	52901	NUT, FLYWHEEL TO CRANKSH	1		
3	30	62567	BEARING, BALL - UPPER	1		
4	30	53853	BEARING, BALL - LOWER	1		
5		54196A 1	CARRIER ASSEMBLY, "O" RING	1	SERIAL 02933580-09999999	
6	25	35126	"O" RING, CARRIER	1	SERIAL 02933580-09999999	4
7	535	3190A 1	CENTER MAIN BEARING ASSEMBLY	2		
8	17	20032	DOWEL PIN, CENTER MAIN BE	4		
9	29	48410	BEARING, NEEDLE - OUTER R	112		
10		26113	RACE, OUTER (PAIR)	2		
11	53	26933	RING, SNAP - OUTER RACE	2		
12	17	47246	DOWEL PIN, STEPPED	2		
13	10	22968	SCREW, CENTER MAIN BEARIN	4		
14	11	46887	NUT, BEARING CLAMPING SCF	4		
15	540	3943A 2	MAIN BEARING ASSEMBLY, VAL	3	SERIAL 00000000-03274149	
15	540	4857A 4	MAIN BEARING ASSEMBLY, VAL	3	SERIAL 03274150-09999999	
16	17	20032	DOWEL PIN, MAIN BEARING	6		
17	10	45775	SCREW, MAIN BEARING CLAMP	6		
18	11	45774	NUT, MAIN BEARING CLAMPIN	6		
19	34	56007A 1	REED SET, MATCHED - MAIN B	3		
20	34	57422	REED STOP, MAIN BEARING BE	12		
21	10	20055	SCREW, REED STOP MOUNTIN	60	SERIAL 00000000-03274149	
21A	10	62204	SCREW, REED STOP MOUNTIN	30	SERIAL 03274150-09999999	
22	11	53153	NUT, REED STOP MOUNTING	30	SERIAL 03274150-09999999	
23	745	4879A 2	PISTON AND PISTON PIN ASSEM	6		
24	40	52035	LOCK RING, PISTON PIN	12		
25	39	45155A12	RING, PISTON (1/16" THICK)	2		
26	622	4850A 4	CONNECTING ROD AND CAP AS	6		
27	31	63075A 1	BEARING ASSEMBLY, CRANKP	6		
28	10	54803	SCREW, CONNECTING ROD	12		
29	11	49091	NUT, CONNECTING ROD SCRE	12		
30	29	47270	BEARING, NEEDLE - PISTON PI	174		
31	12	47247	WASHER, NEEDLE LOCATING	12		