



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1134	3197A 1	END CAP ASSEMBLY, UPPER	1		
2	26	29476	OIL SEAL, END CAP	1		
3	25	47254	"O" RING	1		4
4	15	47248A 1	SHIM, END CAP TO CRANKCASE	AR		
5	10	30225	SCREW, END CAP MOUNTING	4		
6	852	3884A 3	CYLINDER BLOCK AND CRANKC.	1	SERIAL 00000000-03023086	
6	852	4741A 5	CYLINDER BLOCK AND CRANKC.	1	SERIAL 03270480-03274148	
6	852	4843A 5	CYLINDER BLOCK AND CRANKC.	1	SERIAL 03274149-09999999	
7	27	53862	GASKET, CRANKCASE TO CYLI	2		4
8		57854	RESTRICTION, CRANKCASE BL	5		
9	16	35099	STUD, CARBURETOR MOUNTI	6		
10	16	26133	STUD, CRANKCASE TO DRIVE	2		
11	17	20033	PIN, DOWEL - CRANKCASE TO	2		
12	17	20323	PIN, DOWEL - CYLINDER BLOC	3		
13	16	26134	STUD, CYLINDER BLOCK TO D	2		
14	16	48770	STUD, CYLINDER BLOCK TO D	4		
15	16	26324	STUD, CYLINDER BLOCK TO D	2		
16		56029	COVER, STARTER MOTOR BRAC	1		
17	10	26132	SCREW, TOP COVER ATTACHI	1		
17	10	21449	SCREW, TOP COVER ATTACHI	1		
18	11	46793	NUT, COVER SCREW	2		
19		56030	COVER, STARTER MOTOR BR	1		
20	10	33473	SCREW, BOTTOM COVER ATT	1		
20	10	39767	SCREW, BOTTOM COVER ATT	1		
21	11	46793	NUT, COVER SCREW	1		
22	10	33473	SCREW, CRANKCASE TO CYLIN	3		
22	10	32293	SCREW, CRANKCASE TO CYLIN	2		
22	10	21574	SCREW, CRANKCASE TO CYLIN	21		
23	12	22753	WASHER, CRANKCASE TO CYLIN	26		
24	11	46793	NUT, CRANKCASE FASTENING S	26		
25	10	20359	SCREW, CENTER MAIN BEARIN	2		
26	14	20091	TAB WASHER, BEARING LOCKIN	2		
27	1126	3196A 3	END CAP ASSEMBLY, LOWER	1		
28	21	56011A 1	CHECK VALVE ASSEMBLY, EN	1		
29	26	29476	OIL SEAL, END CAP	2		
30	25	20081	"O" RING< END CAP	1		4
31	15	20085A 1	SHIM, END CAP TO CRANKCASE	AR		
32	10	30225	SCREW, END CAP MOUNTING (1	3		
33		55200	COVER, WATER JACKET - CYLIN	1	SERIAL 00000000-03114543	
33		62278	COVER, WATER JACKET - CYLIN	1	SERIAL 03270480-09999999	
34	27	47228	GASKET, WATER JACKET COVER	1		4