



# IGNITION COIL

Parts List					
Ref	Class	Part	Description	Qty	Comment
1	332	2983A 5	IGNITION COIL ASSEMBLY, COMI	1	UNITED STATES 4112634 AND I
2	10	37941	SCREW, COIL MOUNTING BRACH	1	UNITED STATES 4112634 AND I
3	13	26992	LOCKWASHER, COIL MOUNTING	1	UNITED STATES 4112634 AND I
4	10	31471	SCREW, COIL MOUNTING BRACH	2	UNITED STATES 4112634 AND I
5	23	52933	SPACER, COIL BRACKET TO BOT	3	UNITED STATES 4112634 AND I
6	11	46887	NUT, COIL MOUNTING BRACKET	2	UNITED STATES 4112634 AND I
7	332	4895A 2	IGNITION COIL ASSEMBLY	1	UNITED STATES 4112635 AND I
8		63194	PAD, RUBBER - IGNITION COIL	1	UNITED STATES 4112635 AND I
9		63195	COVER, IGNITION COIL	1	UNITED STATES 4112635 AND I
10	10	69046	SCREW, COIL TO CYLINDER BLC	3	UNITED STATES 4112635 AND I
11	12	30164	WASHER, COIL SCREW	3	UNITED STATES 4112635 AND I
12	84	60466A 1	CABLE ASSEMBLY	1	UNITED STATES 4112635 AND I
13	13	26996	LOCKWASHER, IGNITION COIL T	2	UNITED STATES 4112635 AND I
14	11	45076	NUT, IGNITION COIL TERMINAL	2	UNITED STATES 4112635 AND I
15	84	66054A 2	CABLE ASSEMBLY, COIL TO SWI	1	UNITED STATES 4112635 AND I
16	10	62568	SCREW, IGNITION COIL WIRE TC	1	UNITED STATES 4112635 AND I
17		69190	PLATE, COIL MOUNTING	1	UNITED STATES 4112635 AND I