



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	436	4842A 3	CRANKSHAFT ASSEMBLY	1		
2	11	52901	NUT, FLYWHEEL TO CRANKSH	1		
3	30	62567	BEARING, BALL - UPPER	1		
4	30	63742	BEARING, BALL - LOWER	1		
5		54196A 6	CARRIER ASSEMBLY, "O" RING	1		
6		65800	"O" RING, CARRIER	1		4
7	535	3190A 2	CENTER MAIN BEARING ASSEM	2	UNITED STATES 3761034 AND I	
7	535	5397A 4	CENTER MAIN BEARING ASSEM	2	UNITED STATES 3761035 AND I	
8	17	20032	DOWEL PIN, CENTER MAIN BE	4		
9	29	52168	BEARING, NEEDLE - OUTER RA	112		
10		26113	RACE, OUTER (PAIR)	2		
11	53	26933	RING, SNAP - OUTER RACE	2		
12	17	47246	DOWEL PIN, STEPPED	2		
13	10	22968	SCREW, CENTER MAIN BEARIN	4		
14	11	46887	NUT, BEARING CLAMPING SCF	4		
15	540	5055A 6	MAIN BEARING ASSEMBLY, VAL	3	UNITED STATES 3761034 AND I	
15	540	5266A 5	MAIN BEARING ASSEMBLY, VAL	3	UNITED STATES 3761035 AND I	
16	17	20032	DOWEL PIN, MAIN BEARING	6		
17	10	45775	SCREW, MAIN BEARING CLAMP	6		
18	11	45774	NUT, MAIN BEARING CLAMPIN	6		
19	34	56007A 1	REED SET, MATCHED - MAIN B	3		
20	34	56008	REED STOP, MAIN BEARING R	12		
21	10	62204	SCREW, REED STOP MOUNTIN	30		
22	11	53153	NUT, REED STOP SCREW	30		
23	745	5220A 2	PISTON AND PISTON PIN ASSEM	6		
23	745	6388A 3	PISTON AND PISTON PIN ASSEM	6		
24	40	52035	LOCK RING, PISTON PIN	12		
25	39	45155A12	RING PISTON (1/16" THICK)	2		
26	622	4850A 3	CONNECTING ROD AND CAP AS	6		
27	31	62596A 1	BEARING ASSEMBLY, CRANKP	6		
28	10	54803	SCREW, CONNECTING ROD	12		
29	11	49091	NUT, CONNECTING ROD SCRE	12		
30	29	47270	BEARING, NEEDLE - PISTON PI	174		
31	12	47247	WASHER, NEEDLE LOCATING	12		
31	745	5306A 2	PISTON AND PISTON PIN ASSEM	6		
31	774	9137A13	PISTON AND PISTON PIN ASSEM	6		
31	39	45204A12	RING, PISTON 1/16" THICK (OV	2		