



IGNITION COIL

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	332	2983A 5	IGNITION COIL ASSEMBLY, COM	1	UNITED STATES 4112634 AND I	
2	10	37941	SCREW, COIL MOUNTING BRAC	1	UNITED STATES 4112634 AND I	
3	13	26992	LOCKWASHER, COIL MOUNTING	1	UNITED STATES 4112634 AND I	
4	10	31471	SCREW, COIL MOUNTING BRAC	2	UNITED STATES 4112634 AND I	
5	23	52933	SPACER, COIL BRACKET TO BOT	3	UNITED STATES 4112634 AND I	
6	11	46887	NUT, COIL MOUNTING BRACKET	2	UNITED STATES 4112634 AND I	
7	332	4895A 2	IGNITION COIL ASSEMBLY	1	UNITED STATES 4112635 AND I	
8		63194	PAD, RUBBER - IGNITION COIL	1	UNITED STATES 4112635 AND I	
9		63195	COVER, IGNITION COIL	1	UNITED STATES 4112635 AND I	
10	10	69046	SCREW, COIL TO CYLINDER BLC	3	UNITED STATES 4112635 AND I	
11	12	30164	WASHER, COIL SCREW	3	UNITED STATES 4112635 AND I	
12	84	60466A 1	CABLE ASSEMBLY	1	UNITED STATES 4112635 AND I	
13	13	26996	LOCKWASHER, IGNITION COIL T	2	UNITED STATES 4112635 AND I	
14	11	45076	NUT, IGNITION COIL TERMINAL	2	UNITED STATES 4112635 AND I	
15	84	66054A 2	CABLE ASSEMBLY, COIL TO SWI	1	UNITED STATES 4112635 AND I	
16	10	62568	SCREW, IGNITION COIL WIRE TC	1	UNITED STATES 4112635 AND I	
17		69190	PLATE, COIL MOUNTING	1	UNITED STATES 4112635 AND I	