



| Parts List | | | | | | |
|------------|-------|----------|------------------------------|-----|-----------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 393 | 3736A23 | HOUSING ASSEMBLY, DISTRIBU | 1 | | |
| 2 | | 32197 | STOP, SPARK ADVANCE - DISTR | 1 | | |
| 3 | 17 | 27962 | PIN, ANCHOR SPRING - DISTRIB | 1 | | |
| 4 | 24 | 27944 | SPRING, HORSESHOE - DISTRIB | 1 | | |
| 5 | 12 | 53540 | WASHER, ECONOMIZER COLLA | 1 | | |
| 6 | | 55804A 1 | ECONOMIZER COLLAR ASSEMBL | 1 | | |
| 7 | 17 | 27961 | PIN, ECONOMIZER COLLAR - S | 1 | | |
| 8 | 22 | 25094 | FITTING, GREASE - ECONOMIZ | 1 | | |
| 9 | | 27947 | SWIVEL, LINKAGE - ECONOMIZE | 1 | | |
| 10 | | 25996A 1 | SWIVEL AND LINK ROD ASSEMB | 1 | UNITED STATES 3761034 AND I | |
| 11 | 11 | 64484 | NUT, UPPER LINK ROD ADJUSTI | 1 | UNITED STATES 3761034 AND I | |
| 12 | | 37700 | ROD, LINK - UPPER | 1 | UNITED STATES 3761034 AND I | |
| 12A | | 67469 | ROD, LINK - UPPER | 1 | UNITED STATES 3761035 AND I | |
| 13 | | 27948 | SWIVEL, UPPER LINK ROD TO T | 1 | | |
| 14 | | 60478 | LEVER, THROTTLE CONTROL | 1 | | |
| 15 | 13 | 39954 | WASHER, WAVE-THROTTLE COI | 1 | | |
| 16 | 12 | 29245 | WASHER, THROTTLE CONTROL | 1 | | |
| 17 | 11 | 35888 | NUT, UPPER LINK ROD THROTT | 1 | | |
| 18 | 10 | 37559 | SCREW, THROTTLE LEVER TO E | 1 | | |
| 19 | 12 | 29395 | WASHER, THROTTLE CONTROL | 1 | | |
| 20 | 23 | 45818 | BUSHING, THROTTLE CONTROL | 1 | | |
| 21 | 11 | 20509 | NUT, THROTTLE CONTROL LEVI | 1 | | |
| 22 | | 37587 | SWIVEL, LOWER - THROTTLE CI | 1 | | |
| 23 | 11 | 35888 | NUT, THROTTLE CABLE TO LOW | 1 | | |
| 24 | | 48692 | COLLAR, THROTTLE ACTUATOR | 1 | | |
| 25 | 10 | 48675 | SCREW, ADJUSTING - THROTTL | 1 | | |
| 26 | 11 | 64015 | NUT, THROTTLE ACTUATOR CO | 1 | | |
| 27 | | 52023 | CAP, NYLON - THROTTLE ACTU | 1 | | |
| 28 | | 48671 | PLATE, THROTTLE ACTUATOR | 1 | | |
| 29 | 10 | 37892 | SCREW, THROTTLE ACTUATOR | 2 | | |
| 30 | 12 | 30164 | WASHER, THROTTLE ACTUATO | 2 | | |
| 31 | 13 | 26996 | LOCKWASHER, THROTTLE ACTI | 2 | | |
| 32 | 23 | 48674 | SPACER, THROTTLE ACTUATO | 2 | | |
| 33 | | 58454 | CAM, THROTTLE ACTUATOR PL | 1 | | |
| 34 | 12 | 46246 | WASHER, ADAPTOR - DISTRIBU | 1 | | |
| 35 | | 48666A 1 | ADAPTOR ASSEMBLY, DISTRIBL | 1 | UNITED STATES 3761034 AND I | |
| 35 | | 66165A 2 | ADAPTOR ASSEMBLY, DISTRIBL | 1 | UNITED STATES 3761035 AND I | |
| 36 | 22 | 25094 | FITTING, GREASE - DISTRIBU | 1 | | |
| 37 | 10 | 22040 | SCREW, DISTRIBUTOR HOUSINI | 3 | UNITED STATES 3761034 AND I | |
| 37 | 10 | 20362 | SCREW, DISTRIBUTOR HOUSINI | 3 | UNITED STATES 3761035 AND I | |
| 38 | 12 | 20084 | WASHER, DISTRIBUTOR HOUSI | 2 | | |