



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1368	5290A 6	CARBURETOR ASSEMBLY	3	UNITED STATES 3761035 THRL	
1	1368	5702A 5	CARBURETOR ASSEMBLY	3	UNITED STATES 4112635 AND I	
2	1395	5353	FLOAT ASSEMBLY	3		
3			PIN, FLOAT LEVER PINION	6		3
4			LEVER, FLOAT (LOWER)	3		3
5			LEVER, FLOAT (UPPER)	3		3
6	1395	4555	INLET NEEDLE, SEAT AND GA	3	UNITED STATES 3761035 THRL	
6	1395	4868	INLET NEEDLE, SEAT AND GA	3	UNITED STATES 4112635 AND I	
7			GASKET, INLET SEAT	3		3,0
8			GASKET, FLOAT BOWL COVER	3		3,0
9	1395	5261	COVER, FLOAT BOWL	3	UNITED STATES 3761035 THRL	
10	1395	5680	COVER, FLOAT BOWL	3	UNITED STATES 4112635 AND I	
11	1395	5733	JET, BOWL VENT	3	UNITED STATES 4112635 AND I	
12	1395	5734	HOSE, ECONOMIZER	3	UNITED STATES 4112635 AND I	
13	10	52195	SCREW, FLOAT BOWL COVER	6	UNITED STATES 3761035 THRL	
13	10	52195	SCREW, FLOAT BOWL COVER	3	UNITED STATES 4112635 AND I	
14	1395	4804	SCREW, FLOAT BOWL COVER	3	UNITED STATES 4112635 AND I	
15	13	26995	LOCKWASHER, FLOAT BOWL C	6		
16	1395	4805	SCREEN, FILTER	3		3
17	1399	97	LEVER, THROTTLE STOP	3	USED ON CENTER AND LOWEF	
18	10	20847	SCREW, THROTTLE STOP LEV	3		
19	1399	3527	SHAFT, THROTTLE	3		
20			TUBE, IDLE	3		3
21	1395	4540	SCREW, BODY (IDLE TUBE)	3		
22	1395	5108	SHUTTER, THROTTLE	3		
23			SCREW AND LOCKWASHER, T	6		3
24			SPRING, IDLE ADJUSTMENT S	3		3
25	1399	3515	SCREW, IDLE ADJUSTMENT	3		
26			NOZZLE, MAIN	3		3
27	1395	4542	SCREW, PLUG - MAIN NOZZLE	3		
28	1399	3794	JET, MAIN FUEL (.074)	OPT		
28	1399	3795	JET, MAIN FUEL (.072) - STAND	3		3
28	1399	3811	JET, MAIN FUEL (.070)	OPT		
28	1399	4214	JET, MAIN FUEL (.068)	OPT		
29	1395	4541	SCREW, PLUG - MAIN FUEL JE	3		
30			GASKET, JET CHANNEL PLUG	3		3,0
31			SPRING, THROTTLE SHAFT RE	3		3
32	1395	4543	SCREW, BODY CHANNEL	3		
33			WELCH PLUG, BODY CHANNEL	3		3
33	1395	4808	GASKET AND PACKING SET (1 PI	3		
33	1395	5405	REPAIR PARTS KIT (1 PER CARB	2		