



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1352	4510A24	CARBURETOR ASSEMBLY (WMK)	3	
2	1399	110A 1	FLOAT ASSEMBLY	3	
3			PIN, FLOAT LEVER PINION	6	3
4			LEVER, FLOAT (LOWER)	3	3
5			LEVER, FLOAT (UPPER)	3	3
6	1395	4555	INLET NEEDLE, SEAT AND GASKET	3	3
7			GASKET, INLET SEAT	3	3,0
8			GASKET, FLOAT BOWL COVER	3	3,0
9	1399	4559	COVER, FLOAT BOWL	3	
10	10	52195	SCREW, FLOAT BOWL COVER	3	
11	10	52196	SCREW, FLOAT BOWL COVER	3	
12	13	26995	LOCKWASHER, FLOAT BOWL COVER	6	
13	27	25851	GASKET, STRAINER COVER (SC)	3	
14	1399	3938	SCREEN, FILTER	3	3
15	27	25849	GASKET, STRAINER COVER (SC)	3	
16	1399	4791	COVER, STRAINER	3	
17			GASKET, STRAINER COVER SC	3	3,0
18	10	25822	SCREW, STRAINER COVER FA	3	3
19	10	20847	SCREW, THROTTLE STOP LEV	3	3
20	1399	97	LEVER, THROTTLE STOP (SEE 20)	3	USED ON CENTER AND LOWE
21	1399	3527	SHAFT, THROTTLE	3	
22			TUBE, IDLE	3	3
23	1395	4540	SCREW, BODY (IDLE TUBE)	3	
24			SCREW AND LOCKWASHER, T	6	3
25	1395	5108	SHUTTER, THROTTLE	3	
26			SPRING, IDLE ADJUSTMENT S	3	3
27	1399	3515	SCREW, IDLE ADJUSTMENT	3	3
28	1395	4541	SCREW, PLUG - MAIN FUEL JE	3	
29			GASKET, JET CHANNEL PLUG	3	3,0
30	1399	3794	JET, MAIN FUEL (.074)	OPT	
30	1399	3795	JET, MAIN FUEL (.072) - STAND	3	3
30	1399	3811	JET, MAIN FUEL (.070)	OPT	
30	1399	4214	JET, MAIN FUEL (.068)	OPT	
31			NOZZLE, MAIN	3	3
32	1395	4542	SCREW, PLUG - MAIN NOZZLE	3	
33			SPRING, THROTTLE SHAFT RE	2	3
34			WELCH PLUG, BODY CHANNEL	3	3
35	1395	4543	SCREW, BODY CHANNEL	3	
35	1399	3523	GASKET AND PACKING SET (1 PI	3	3
35	1395	5109	REPAIR PARTS KIT (1 PER CARB	3	
36	27	48164	GASKET, CARBURETOR FLANGE	2	4