



A=TO FUEL PUMP

| Parts List | | | | | | |
|------------|-------|-----------|-------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 1278 | 828362A 3 | OIL TANK ASSEMBLY | 1 | | |
| 2 | 36 | 821902A 1 | COVER ASSEMBLY | 1 | | |
| 3 | 27 | 822061 2 | GASKET | 1 | | |
| 4 | | 824612 | LATCH | 1 | | |
| 5 | 24 | 824611 | SPRING | 1 | | |
| 6 | 10 | 40056 66 | SCREW | 2 | | |
| 7 | 12 | 27882 | WASHER | 2 | | |
| 8 | 17 | 822059 | GROOVE PIN | 1 | | |
| 8 | 17 | 825259 | ROLL PIN (.093 X 1.250) | 1 | | |
| 9 | | 19299A 1 | VENT ASSEMBLY | 1 | | |
| 10 | 21 | 64871 | VALVE | 1 | | |
| 11 | 10 | 40106 30 | SCREW | 1 | | |
| 12 | 12 | 40023 16 | WASHER | 1 | | |
| 13 | 25 | 42117 | GROMMET | 1 | | |
| 14 | 23 | 42116 | BUSHING | 1 | | |
| 15 | | 99161 | BOOT | 1 | | |
| 16 | | 42888 | BASE | 1 | | |
| 17 | 10 | 821550 50 | SCREW | 2 | | |
| 18 | 87 | 12886A 6 | SWITCH ASSEMBLY | 1 | | |
| 19 | 10 | 58376 | SCREW | 1 | | |
| 20 | 12 | 72761 | WASHER | 1 | | |
| 21 | 43 | 43020 4 | DRIVEN GEAR | 1 | | |
| 22 | 25 | 62705 | O-RING | 2 | | 1 |
| 23 | | 17335A 3 | ADAPTOR ASSEMBLY | 1 | | |
| 24 | 23 | 17597 | BUSHING | 1 | | |
| 25 | 23 | 17596 | JOURNAL BUSHING | 1 | | |
| 26 | | 44345 3 | OIL PUMP | 1 | | |
| 27 | 10 | 821045 40 | SCREW | 2 | | |
| 28 | 32 | 823813 29 | TUBING (5-1/2 IN.) | 1 | | |
| 29 | 32 | 823814 55 | TUBING (11 IN.) | 1 | | |
| 30 | 54 | 816311 | STA-STRAP (8 IN.) | AR | | 9 |
| 30 | | 69355 | STA-STRAP (5-1/2 IN.) | AR | | 9 |
| . | 27 | 13461A90 | GASKET SET | 1 | | |