



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1440	3291A 1	CLAMP BRACKET ASSEMBLY	2,2		
2		28403A 3	THUMB SCREW ASSEMBLY	2,2		
3	12	28404	WAHSER, THUMB SCREW	2,2		
4		30664	TUBE, TILT - CLAMP BRACKET T	1,1		
5	15	30497A 1	SHIM, CLAMP BRACKET TILT TU	2,		
5	12	52864	WASHER, CLAMP BRACKET TILT	,2		
6	11	30499	NUT, TILT TUBE FASTENING	2,2		
7		53078	CAP, PLASTIC - TILT TUBE	2,2		
8	23	20222	SPACER, CLAMP BRACKET STUC	1,1		
10	13	26993	LOCKWASHER, CLAMP BRACKET	2,2		
11	11	20083	NUT, CLAMP BRACKET STUD	2,2		
12	17	49930A 1	TILT LOCK PIN ASSEMBLY	1,1		
13	32	28052	SLEEVE, RUBBER - TILT PIN BUN	1,1		
14	1453	3258A 1	SWIVEL BRACKET ASSEMBLY (S	1,1		
14	1447	3257A 1	SWIVEL BRACKET ASSEMBLY (L	1,1		
15	26	37448	OIL SEAL, SWIVEL BRACKET	2,2		
16	10	47828	SCREW, DRIVE - SWIVEL BRAC	1,1		
17	22	23612	FITTING, GREASE - SWIVEL BF	1,1		
18		53216	LUBRICAP, SWIVEL BRACKET GF	1,1		
19	24	28659	SPRING, COIL - SWIVEL BRACKE	1,1		
20	17	38311	PIN, COIL SPRING MOUNTING	1,1		
21		47799A 1	TILT LOCK ASEMBLY, STARBOAF	1,1		
22		47800A 1	TILT LOCK ASEMBLY, PORT	1,1		
23		47802	TUBE, TILT LOCK	1,1		
24	18	47959	COTTER PIN, TILT LOCK TUBE	2,2		
25	23	47803	BUSHING, TILT LOCK TUBE	2,2		
26	13	24850	WASHER, WAVE - TILT LOCK TU	2,2		
27	17	49841A 1	SWIVEL PIN AND STEERING ARM	1,1		
27	17	49840A 1	SWIVEL PIN AND STEERING ARM	1,1		
28		28203	BUMPER, STEERING ARM	1,1		
29	10	49554	BOLT, STEERING ARM TO UPPE	2,2		
30	11	22178	NUT, STEERING ARM BOLT FAS	2,2		
31	10	31830	SCREW, RIDE-GUIDE ATTACHIN	1,1		
32	11	20509	NUT, RIDE-GUIDE ATTACHING S	1,1		
33	12	37429	WASHER, SWIVEL PIN - LOWER	1,1		
34		37419	YOKE, BOTTOM	1,1		
35	11	37424	NUT, SWIVEL PIN RETAINING	1,1		
36		28205	STRAP STOP, DRIVE SHAFT HOL	1,1		
37	10	28200	SCREW, STRAP STOP TO DRIVE	1,1		
38	11	25269	NUT, STRAP STOP FASTENING	1,1		
39	22	28208	SPACER, RUBBER - COIL SPRING	2,2		