



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		27947	SWIVEL, LINKAGE - ECONOMIZE	1,1		
2		25996A 1	SWIVEL AND LINK ROD ASSEMB	1,1		
3	11	25168	NUT, UPPER LINK ROD ADJUSTI	1,1		
4		37700	ROD, LINK - UPPER	1,1		
5		27948	SWIVEL, UPPER LINK ROD TO T	1,1		
6		48856	LEVER, THROTTLE CONTROL	1,1		
7	12	29245	WASHER, THROTTLE CONTROL	1,1		
8	13	25806	WASHER, WAVE - THROTTLE CC	1,1		
9	11	20361	NUT, UPPER LINK ROD SWIVEL	1,1		
10	10	37559	SCREW, THROTTLE LEVER TO E	1,1		
11	12	29395	WASHER, THROTTLE CONTROL	1,1		
12	23	45818	BUSHING, THROTTLE CONTROL	1,1		
13	11	20509	NUT, THROTTLE CONTROL LEVI	1,1		
14		37587	SWIVEL, LOWER - THROTTLE CI	1,1		
15	11	20361	NUT, THROTTLE CABLE TO LOW	1,1		
16	393	2799A11	DISTRIBUTOR ASSEMBLY, COMI	1,1		
17		45409	WIRE RETAINER, HIGH TENSION	2,2		
18		45392	BRACKET, FRONT - WIRE RETAI	1,1		
19		47398	BRACKET, REAR - WIRE RETAIN	1,1		
20	10	30663	SCREW, FRONT AND REAR BRA	4,4		
21		45391	SPACER, RUBBER - HIGH TENSIO	2,2		
22	33	45191	SPARK PLUG (CHAMPION - L19V)	6,6		
23	32	26542	HOSE, VENT - DISTRIBUTOR TO	1,1		
24	32	52030	HOSE, VENT - DISTRIBUTOR TO	1,1		
25	22	31521	ELBOW, VENT HOSE TO BOTTOI	2,2		
26	54	22875	CLAMP, VENT HOSE TO BOTTON	1,1		
27	10	48591	SCREW, VENT HOSE CLAMP TO	1,1		
28		22789	"D" WASHER, VENT HOSE CLAM	1,1		
29	11	24656	NUT, VENT HOSE CLAMP SCREW	1,1		
30	332	2983A 5	IGNITION COIL ASSEMBLY, COMI	1,1		
31	10	46368	SCREW, IGNITION COIL CLAMP	1,1		
31	10	46367	SCREW, IGNITION COIL CLAMP	1,1		
32	11	20645	NUT, IGNITION COIL CLAMPING	1,1		
33	12	37407	WASHER, IGNITION COIL CLAM	1,1		
34	54	22740	CLIP, LEAD WIRE TO IGNITION	1,1		
35		22789	"D" WASHER, IGNITION COIL C	1,1		
36	11	20190	NUT, IGNITION COIL CLAMPING	2,2		
37	10	22486	SCREW, COIL MOUNTING BRACH	1,1		
38	13	26992	LOCKWASHER, COIL MOUNTING	1,1		
39	10	37561	SCREW, COIL MOUNTING BRACH	2,2		
40	11	46987	NUT, COIL MOUNTING BRACKET	2,2		