



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1552	3377A 1	DRIVE SHAFT HOUSING ASSEM	1	
1	1551	3376A 2	DRIVE SHAFT HOUSING ASSEM	1	
1	1552	3670A 3	DRIVE SHAFT HOUSING ASSEM	1	
1	1551	3669A 4	DRIVE SHAFT HOUSING ASSEM	1	
2	16	47165	STUD, DRIVE SHAFT HOUSING	2	
2	16	46910	STUD, DRIVE SHAFT HOUSING	2	
3	19	47579	PLUG, PLASTIC - TRIM TAB SCRE	1,1	PART OF A-1552-3670A3 AND A-
4	10	48409	SCREW, RETAINING STRIP TO C	2,2	PART OF A-1552-3670A3 AND A-
5	10	48408	SCREW, RETAINING STRIP TO C	6,6	PART OF A-1552-3670A3 AND A-
6		37417	COVER, TRIM - DRIVE SHAFT HC	1,1	
7	10	37571	SCREW, TRIM COVER TO BOTTC	4,4	
8		37919	SEAL, TRIM COVER TO DRIVE SH	1,1	
9		37665	STRIP, RETAINING - COVER SEA	2,2	
10		38052	STRIP, RETAINING - TRIM COVEI	1,1	
11	32	37446	TUBE, WATER INLET (SHORT SH	1,1	
11	32	37438	TUBE, WATER INLET (LONG SHA	1,1	
12	23	29591	SLEEVE, RUBBER - WATER INLE	1	
13		38469	TUBE, EXHAUST (SHORT SHAFT	,1	
13		38470	TUBE, EXHAUST (LONG SHAFT)	,1	
14	10	38601	SCREW, EXHAUST TUBE TO EXH	,2	
15	11	46886	NUT, EXHAUST TUBE SCREW	,2	
16	11	21528	NUT, POWERHEAD STUDS (5/16	2,2	
17	11	20509	NUT, POWERHEAD STUDS (3/8-	2,2	
17	11	23161	NUT, POWERHEAD STUDS (3/8-	6,6	
18	12	20086	WASHER, POWERHEAD STUDS	2,2	
19	27	48801	GASKET, EXHAUST EXTENSION	1,1	4
20		47560	GUIDE, PUSH ROD - REVERSE L	1	
20		52887	GUIDE, PUSH ROD - REVERSE L	,1	
21		47591	ROD, PUSH - REVERSE LOCK (S	1,1	
21		47558	ROD, PUSH - REVERSE LOCK (LC	1,1	
22	11	47661	NUT, JAM - PUSH ROD	1,1	
23		47559	YOKE, PUSH ROD	1,1	
24	17	39023	PIN, PUSH ROD TO REVERSE LC	1,1	
25	18	25191	COTTER PIN, PUSH ROD PIN	1,1	
26		37398	MOUNT, RUBBER - UPPER	2,2	
26		38820	MOUNT, RUBBER - UPPER (HEA)	OPT,01	
27		49239	COVER, UPPER MOUNT - OUTSI	2,2	
28		49238	COVER, UPPER MOUNT - INSIDE	2	
28		53141	COVER, UPPER MOUNT - INSIDE	,2	
29		24929	PACKING, "U" CUP	2,2	
30	10	28772	SCREW, UPPER MOUNT COVER	4,4	