



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2114	3168	COWL, TOP	1		
1	2114	3591	COWL, TOP	.1		
2		47555A 1	RETAINER ASSEMBLY, TOP COV	1		
2		52733A 1	RETAINER ASSEMBLY, TOP COV	.1		
3		35496	PAD, BUMPER _ TOP COWL RE	1,1		
4		46141	EMBLEM, TOP COWL RETAIN	1,1		
5	10	37558	SCREW, RETAINER TO TOP CO	1,1		
6	13	39107	LOCKWASHER, RETAINER TO T	1,1		
7		49448	SHIELD, SHIELD TO TOP COWL	1,1		
8	13	37371	LOCKWASHER, SHIELD SCREW	3,3		
10		47341A 1	ROPE, STARTER (FOR MANUAL	1,1		
11		46144	BRACKET, COWL LATCH TOP CI	2		
12	10	21091	SCREW, COWL LATCH BRACKET	4		
13	12	37998	WASHER, LATCH BRACKET SCR	AR,		
14	12	37998	WASHER, LATCH BRACKET SCR	AR,		
15		37412	LEVER, CLAMPING - TO COWL M	2		
16	23	26819	BUSHING, NYLON - CLAMPING LI	2		
17	12	38006	WASHER, CLAMPING LEVER	2		
18	23	31293	BUSHING, RUBBER - CLAMPING	2		
19	53	30428	FASTNER, CLAMPING LEVER	2		
20	17	29077	PIN, ROLL - CLAMPING LEVER	2		
21		52739	HINGE, COWL LATCH - TOP COW	.1		
22		52737	LEVER, COWL LATCH HINGE	.1		
23	17	33522	PIN, ROLL - COWL LATCH HINGE	.1		
24	24	53019	SPRING, COWL LATCH HINGE	.1		
25		52738	HOOK, TOP COWL LATCH - REAF	.1		
26	10	22956	SCREW, REAR HOOK TO TOP CO	.2		
27	13	26992	LOCKWASHER, REAR HOOK MO	.2		
28		47271	FRAME, TOP COWL SUPPORT	1,1		
29	37	45201	DECAL, TIMING	1		
30		37639	MOUNT, RUBBER - TOP COWL F	3,3		
30		46096	MOUNT, RUBBER - TOP COWL F	OPT,OI		
31	11	20361	NUT, RUBBER MOUNT TO TOP C	6,6		
32		47272	BRACKET, TOP COWL SUPPORT	1,1		
32		54685	BRACKET, TOP COWL SUPPORT	1		
33		31014	MOUNT, RUBBER - REAR SUPPC	.2		
34	13	26992	LOCKWASHER, RUBBER MOUNT	2,2		
35	12	20346	WASHER, RUBBER MOUNT TO F	2,2		
36	11	20088	NUT, RUBBER MOUNT TO REAR	2,2		
37	10	26065	SCREW, REAR BRACKET TO TO	4,4		
38	11	46792	NUT, REAR BRACKET SCREW	4,4		