



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1354	3857	CARBURETOR ASSEMBLY, COM	3		
2	1399	110A 1	FLOAT ASSEMBLY	3		
3			PIN, FLOAT LEVER PINION	6		3
4			LEVER, FLOAT (LOWER)	3		3
5			LEVER, FLOAT (UPPER)	3		3
6	1399	1473	INLET NEEDLE, SEAT AND GA	3		
7			GASKET, INLET SEAT	3		0,3
8			GASKET, FLOAT BOWL COVER	3		3,0
9	1399	1133	COVER, FLOAT BOWL	3		
10	10	52195	SCREW, FLOAD BOWL COVER	3		
11	10	52196	SCREW, FLOAT BOWL COVER	3		
12	13	52194	LOCKWASHER, FLOAT BOWL C	6		
13			GASKET, STRAINER COVER (L	3		3,0
14	1399	3938	SCREEN, FILTER	3		
15			GASKET, STRAINER COVER (S	3		3,0
16	1399	1930	COVER, STRAINER	3		
17			GASKET, STRAINER COVER SC	3		
18	10	25822	SCREW, STRAINER COVER FAS	3		
19	10	20847	SCREW, THROTTLE STOP LEV	3		
20	1399	97	LEVER, THROTTLE STOP	3	USED ON CENTER AND LOWEF	
21	1399	3527	SHAFT, THROTTLE	3		
22			TUBE, IDLE	3		3
22			TUBE, IDLE	3		3
23	10	23178	SCREW, BODY (IDLE TUBE)	3		
24			GASKET, IDLE TUBE	3		3,0
25			SCREW AND LOCKWASHER, TH	6		3
26	1399	3528	SHUTTER, THROTTLE	3		
27			SPRING, IDLE ADJUSTMENT S	3		3
28	1399	3515	SCREW, IDLE ADJUSTMENT	3		
29	10	28405	SCREW, PLUG - MAIN FUEL JE	3		
30			GASKET, JET CHANNEL PLUG	3		3,0
31	1399	3520	JET, MAIN FUEL (.0785)	OPT.		
31	1399	3796	JET, MAIN FUEL (.076) - STAND	3		
31	1399	3794	JET, MAIN FUEL (.074)	OPT.		
31	1399	3795	JET, MAIN FUEL (.072)	OPT.		
32			NOZZLE, MAIN	3		3
33	1399	3522	SCREW, PLUG - MAIN NOZZLE	3		
34			SPRING, THROTTLE SHAFT RE	2	CENTER AND LOWER CARBUR	3
34			SPRING, THROTTLE SHAFT RE	1		3
35			WELCH PLUG, BODY CHANNEL	3		3
35	10	22020	SCREW, BODY CHANNEL	2		