



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		26083	COVER, FUEL PUMP MOUNT	1	
2	10	28711	SCREW, COVER ATTACHING	3	
3		53123A 4	FUEL PUMP ASSEMBLY - UPPER	1	
4	21	30430A 1	CHECK VALVE ASSEMBLY	1	
5		23014A 1	DIAPHRAGM KIT	1	4
6			GASKET, CHECK VALVE TO	2	2
7			GASKET, FUEL PUMP	2	2
8			GASKET, FUEL PUMP COVER	1	2
9		23004	RETAINER, CHECK VALVE	1	
10	10	20037	SCREW, RETAINER TO HOUSII	2	
11		54817A 3	FUEL PUMP ASSEMBLY - LOWER	1	
12	10	38036	SCREW, FUEL PUMP MOUNTING	2	
13	10	30273	SCREW, FUEL PUMP MOUNTING	4	
14	32	32256A 1	FUEL LINE ASSEMBLY, PUMP TC	1	
15	22	30174	ELBOW, UPPER CARBURETOR	1	
16	22	30175	SLEEVE, CARBURETOR STRAINI	1	
17	22	30177	NUT, UPPER CARBURETOR STF	1	
18	54	22627	CLIP, FUEL LINE TO CYLINDER B	1	
19	10	30663	SCREW, FUEL LINE CLIP TO CYL	1	
20		22789	"D" WASHER, FUEL LINE CLIP SI	1	
21	22	32802	PLUG, PIPE - FUEL PUMP	2	
22	32	54739A 1	FUEL LINE ASSEMBLY, PUMP TC	1	6
23	32	52943A 1	FUEL LINE ASSEMBLY, PUMP TC	1	
24	22	54818	"Y" FITTING, UPPER FUEL PUMP	1	6
25	22	30468	CONNECTOR, "Y" FITTING	1	
26	22	30175	SLEEVE, "Y" FITTING CONNECTI	1	
27	22	30177	NUT, "Y" FITTING CONNECTOR	1	
28	32	30176	FUEL LINE, ADAPTOR TO LOWE	1	
29		30186	ADAPTOR, CHECK UNIT (FUEL LI	1	
30		30187	STEM, CHECK UNIT ADAPTOR	1	
31	25	20415	"O" RING, ADAPTOR STEM	1	4
32	24	30189	SPRING, ADAPTOR STEM	1	
33		30188	CUP WASHER, ADAPTOR	1	
34	10	27661	SCREW, ADAPTOR TO BOTTOM	2	