



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1	1440	3296A	1 CLAMP BRACKET ASSEMBLY	2			
2		28403A	3 THUMB SCREW ASSEMBLY	2			
3		28404	WASHER, THUMB SCREW	2			
4	38	39784	SERIAL PLATE	1			
5	10	25612	SCREW, SERIAL PLATE TO SWIV	4			
6	17	48883A	1 SWIVEL PIN AND STEERING ARM	1			
7	26	52924	SEAL, RUBBER - SWIVEL PIN	1			
8	10	49373	BOLT, STEERING ARM TO UPPER	2			
9	11	22178	NUT, STEERING ARM BOLT	2			
10	1453	3466A	1 SWIVEL BRACKET ASSEMBLY	1			
11	26	37448	OIL SEAL, SWIVEL BRACKET	2			
12	10	47828	SCREW, DRIVE - SWIVEL BRAC	1			
13	22	23612	FITTING, GREASE - SWIVEL BF	1			
14		29359	LUBRICAP, SWIVEL BRACKET Gf	1			
15		30664	TUBE, TILT - CLAMP BRACKET T	1			
16	15	30497A	1 SHIM ASSEMBLY, CLAMP BRACK	AR			
17	11	30499	NUT, TILT TUBE FASTENTING	2			
18		53078	CAP, PLASTIC - TILT TUBE	2			
19	23	20222	SPACER, CLAMP BRACKET STUD	1			
20	16	20221	STUD, CLAMP BRACKET	1			
21	12	24812	WASHER, CLAMP BRACKET STU	2			
22	11	25594	NUT, CLAMP BRACKET STUD	2			
23	10	49369	SCREW, TILT LOCK PIN (9-3/8")	1			
24	12	37828	WASHER, TILT LOCK PIN SCREW	1			
25	11	34932	NUT, TILT LOCK PIN SCREW	1			
26	10	28009	BOLT, CLAMP BRACKET TO BOA	2			
27	12	28008	WASHER, CLAMP BRACKET BOL	2			
28	11	28010	NUT, CLAMP BRACKET BOLT	2			
29		30126A	1 TILT STOP LEVER ASSEMBLY	1			
30	10	30128	SCREW, TILT STOP LEVER TO C	2			
31	13	31030	WASHER, WAVE - TILT STOP LE	2			
32	11	46793	NUT, TILT STOP LEVER SCREW	2			
33	55	49577	PIN, LOWER EYE BOLT MOUNTII	2			
34	12	37429	WASHER, SWIVEL PIN	1			
35	12	48926	WASHER, SWIVEL PIN	2			
36		48884	YOKE, BOTTOM	1			
37	11	37424	NUT, SWIVEL PIN RETAINING	1			
38	10	48924	SCREW, YOKE TO DRIVE SHAFT	2			
39	12	24501	WASHER, YOKE SCREW	2			
40	11	35000	NUT, YOKE SCREW	2			
41		49892A	1 EYE BOLT ASSEMBLY	2			