



| Parts List | | | | | | |
|------------|-------|----------|-----------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 52769 | WIRING HARNESS, INTERNAL | 1 | | |
| 2 | 54 | 52876 | CLAMP, WIRING HARNESS TO B | 1 | | |
| 3 | 10 | 45862 | SCREW, WIRING HARNESS CLAI | 2 | | |
| 4 | 13 | 26996 | LOCKWASHER, WIRING HARNE | 2 | | |
| 5 | 12 | 20128 | WASHER, WIRING HARNESS CL | 2 | | |
| 6 | 24 | 28975 | SPRING, GARTER - INTERNAL | 1 | | |
| 7 | 10 | 20776 | SCREW, GROUND WIRE TO BOT | 1 | | |
| 8 | 13 | 24669 | LOCKWASHER, GROUND WIRE | 1 | | |
| 9 | 25 | 26547 | GROMMET, RECTIFIER TO SWIT | 1 | | |
| 10 | 54 | 26538 | CLIP, WIRING HARNESS TO FRO | 1 | | |
| 11 | | 45559 | TERMINAL BLOCK, STATOR LEA | 1 | | |
| 12 | 10 | 48409 | SCREW, TERMINAL BLOCK FAST | 2 | | |
| 13 | 10 | 30663 | SCREW, STATOR LEADS TO TEF | 2 | | |
| 14 | 332 | 2986A 9 | SWITCH BOX ASSEMBLY (MERC | 1 | | |
| 14 | 332 | 2986A 7 | SWITCH BOX ASSEMBLY (MERC | 1 | | |
| 15 | 12 | 45075 | WASHER, SWITCH BOX TERMIN | 7 | | |
| 16 | 11 | 45076 | NUT, SWITCH BOX TERMINAL | 7 | | |
| 17 | 10 | 45218 | SCREW, SWITCH BOX (3/8") | 1 | | |
| 18 | 10 | 24866 | SCREW, SWITCH BOX TO FRON | 4 | | |
| 19 | 11 | 46887 | NUT, SWITCH BOX SCREW | 4 | | |
| 20 | | 25596 | CABLE, WIRE - STARTER MOTO | 1 | | |
| 21 | 10 | 29197 | SCREW, WIRE CABLE TO START | 1 | | |
| 22 | 50 | 55304A 1 | STARTER MOTOR ASSEMBLY (S | 1 | | |
| 23 | 10 | 20362 | SCREW, STARTER MOTOR TO C | 1 | | |
| 24 | 10 | 31984 | SCREW, STARTER MOTOR TO C | 1 | | |
| 25 | 13 | 26993 | LOCKWASHER, STARTER MOTO | 2 | | |
| 26 | | 53507 | BRACKET, STARTER MOTOR SU | 1 | | |
| 27 | 12 | 20103 | WASHER, STARTER MOTOR MO | 2 | | |
| 28 | 11 | 35814 | NUT, STARTER MOTOR MOUNT | 2 | | |
| 29 | 13 | 26992 | LOCKWASHER, STARTER MOTO | 1 | | |
| 30 | 11 | 20890 | NUT, STARTER MOTOR TERMIN | 1 | | |
| 31 | | 25661 | SOLENOID, STARTER | 1 | | |
| 32 | 10 | 2125 | SCREW, SOLENOID TO COIL BR | 2 | | |
| 33 | 13 | 26992 | LOCKWASHER, STARTER SOLE | 2 | | |
| 34 | | 26901 | BUMPER, RUBBER - STARTER S | 1 | | |
| 35 | 13 | 26996 | LOCKWASTER, SOLENOID TERM | 2 | | |
| 36 | 11 | 20645 | NUT, SOLENOID TERMINAL (#10 | 2 | | |
| 37 | | 48396 | CABLE, WIRE - STARTER MOTO | 1 | | |
| 38 | 13 | 26993 | LOCKWASHER, SOLENOID TERM | 2 | | |
| 39 | 11 | 20083 | NUT, SOLENOID TERMINAL (5/1 | 2 | | |
| 40 | | 46265 | ROOT, SOLENOID TERMINAL | 1 | | |