



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1440	3296A 1	CLAMP BRACKET ASSEMBLY	2	
2		28403A 3	THUMB SCREW ASSEMBLY	2	
3		28404	WASHER, THUMB SCREW	2	
4	38	39784	SERIAL PLATE	1	
5	10	25612	SCREW, SERIAL PLATE TO SWI	4	
6	17	48883A 1	SWIVEL PIN AND STEERING ARM	1	
6	17	53776A 1	SWIVEL PIN AND STEERING ARM	1	
7	26	52924	SEAL, RUBBER - SWIVEL PIN	1	
8	10	49373	BOLT, STEERING ARM TO UPPE	2	
9	11	34933	NUT, STEERING ARM BOLT	2	
10	1453	3466A 1	SWIVEL BRACKET ASSEMBLY (S	1	
10	1464	3859A 1	SWIVEL BRACKET ASSEMBLY (L	1	
11	26	37448	OIL SEAL, SWIVEL BRACKET	2	
12	23	54191	BUSHING SWIVEL BRACKET	2	
13	10	47828	SCREW, DRIVE - SWIVEL BRAC	1	
14	22	23612	FITTING, GREASE - SWIVEL BF	1	
15		53216	LUBRICAP, SWIVEL BRACKET G	1	
16		30664	TUBE, TILT - CLAMP BRACKET T	1	
17	12	52864	WASHER, CLAMP BRACKET TILT	2	
18	11	30499	NUT, TILT TUBE FASTENING	2	
19		53078	CAP, PLASTIC - TILT TUBE	2	
20	23	20222	SPACER, CLAMP BRACKET STU	1	
21	16	20221	STUD, CLAMP BRACKET	1	
22	12	24812	WASHER, CLAMP BRACKET STU	2	
23	11	25594	NUT, CLAMP BRACKET STUD	2	
24	10	49369	SCREW, TILT LOCK PIN (9 3/8")	1	
25	12	37828	WASHER, TILT LOCK PIN SCREW	1	
26	11	34932	NUT, TILT LOCK PIN SCREW	1	
27	10	28009	BOLT, CLAMP BRACKET TO BOA	2	
27	10	31827	BOLT, CLAMP BRACKET TO BOA	2	
28	12	28008	WASHER, CLAMP BRACKET BOL	2	
28	12	21040	WASHER, CLAMP BRACKET BOL	2	
29	11	28010	NUT, CLAMP BRACKET BOLT	4	
30		30126A 1	TILT STOP LEVER ASSEMBLY (S	1	
31	10	30128	SCREW, TILT STOP LEVER TO C	2	
32	13	31030	WASHER, WAVE - TILT STOP LE	2	
33	11	46793	NUT, TILT STOP LEVER SCREW	2	
34		47799A 1	TILT LOCK ASSEMBLY, STARBO	1	
35		47800A 1	TILT LOCK ASSEMBLY, PORT (LC	1	
36		47802	TUBE, TILT LOCK (LONG SHAFT)	1	
37	18	47959	COTTER PIN, TILT LOCK TUBE	2	