



| Parts List |       |        |                              |     |         |          |
|------------|-------|--------|------------------------------|-----|---------|----------|
| Ref        | Class | Part   | Description                  | Qty | Comment | Footnote |
| 1          | 2114  | 3806   | COWL, TOP                    | 1   |         |          |
| 2          |       | 52733A | 2 RETAINER ASSEMBLY, TOP COV | 1   |         |          |
| 3          |       | 35496  | PAD, BUMPER - TOP COWL RE    | 1   |         |          |
| 4          | 10    | 37558  | SCREW, RETAINER TO TOP COV   | 1   |         |          |
| 5          | 13    | 39107  | LOCKWASHER, RETAINER TO TI   | 1   |         |          |
| 6          |       | 49448  | SHIELD, TOP COWL - REAR      | 1   |         |          |
| 7          | 10    | 37370  | SCREW, SHIELD TO TOP COV     | 3   |         |          |
| 8          | 13    | 37371  | LOCKWASHER, SHIELD SCREW     | 3   |         |          |
| 9          |       | 47341A | 1 ROPE, STARTER (FOR MANUAL  | 1   |         |          |
| 10         |       | 52739  | HINGE, COWL LATCH - TOP COV  | 1   |         |          |
| 11         |       | 52737  | LEVER, COWL LATCH HINGE      | 1   |         |          |
| 12         | 17    | 33522  | PIN, ROLL - COWL LATCH LEVE  | 1   |         |          |
| 13         | 24    | 53019  | SPRING, COWL LATCH HINGE     | 1   |         |          |
| 14         |       | 52738  | HOOK, TOP COWL LATCH - REAF  | 1   |         |          |
| 15         | 10    | 22956  | SCREW, REAR HOOK TO TOP CC   | 2   |         |          |
| 16         | 13    | 26992  | LOCKWASHER, REAR HOOK MO     | 2   |         |          |
| 17         |       | 48825  | FRAME, TOP COWL SUPPORT      | 1   |         |          |
| 18         |       | 37639  | MOUNT, RUBBER-TOP COWL FR    | 1   |         |          |
| 18         |       | 46096  | MOUNT, RUBBER - TOP COWL F   | 2   |         |          |
| 19         | 11    | 20361  | NUT, RUBBER MOUNT TO TOP C   | 2   |         |          |
| 19         | 11    | 21528  | NUT, RUBBER MOUNT TO TOP C   | 4   |         |          |
| 20         |       | 54685  | BRACKET, TOP COWL SUPPORT    | 1   |         |          |
| 21         |       | 31014  | MOUNT, RUBBER - REAR SUPPC   | 2   |         |          |
| 22         | 13    | 26992  | LOCKWASHER, RUBBER MOUNT     | 2   |         |          |
| 23         | 12    | 20346  | WASHER, RUBBER MOUNT TO F    | 2   |         |          |
| 24         | 11    | 20088  | NUT, RUBBER MOUNT TO REAR    | 2   |         |          |
| 25         | 10    | 26065  | SCREW, REAR BRACKET TO TOI   | 4   |         |          |
| 26         | 11    | 46793  | NUT, REAR BRACKET SCREW      | 4   |         |          |
| 27         | 10    | 24234  | SCREW, REAR BRACKET TO BOT   | 4   |         |          |
| 28         | 13    | 26993  | LOCKWASHER, REAR SUPPORT     | 4   |         |          |
| 29         |       | 52725A | 2 BRACKET ASSEMBLY, TOP COW  | 1   |         |          |
| 30         | 10    | 22040  | SCREW, FRONT BRACKET TO BI   | 2   |         |          |
| 31         | 11    | 46793  | NUT, FRONT SUPPORT BRACKE    | 2   |         |          |
| 32         | 10    | 20362  | SCREW, FRONT BRACKET TO TI   | 2   |         |          |
| 33         | 13    | 26993  | LOCKWASHER, FRONT SUPPOR     | 2   |         |          |
| 34         |       | 37640  | MOUNT, RUBBER - FRONT SUPP   | 1   |         |          |
| 35         | 13    | 26993  | LOCKWASHER, RUBBER MOUNT     | 1   |         |          |
| 36         | 11    | 22053  | NUT, RUBBER MOUNT TO FRON    | 1   |         |          |