



1396

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		NSS	NOT SOLD SEPARATE, Oil Filter V	1		
2	91	83164M	FLYWHEEL PULLER	1		
3	91	83163M	FLYWHEEL HOLDER	1		
4		FT2997	PISTON RING COMPRESSOR	1		
6	91	809494A	VALVE SPRING COMPRESSOR	1		
7	91	809495A	VALVE GUIDE REMOVER	1		
8	91	809496A	VALVE GUIDE INSTALLER BUSH	1		
9	91	809497A	VALVE GUIDE REAMER	1		
10		NSS	NOT SOLD SEPARATE, Valve Se	1		
11	91	828999	WRENCH	1		
12	91	37241	PULLER PLATE	1		
13	91	83165T	PULLER ASSEMBLY	1		
14	91	34569A	PULLER ASSEMBLY, Slide Hamme	1		
15	91	13664	BEARING CARRIER TOOL	1	(Non-Bigfoot)	
15	91	93843T	BEARING CARRIER TOOL	1	(Bigfoot)	
16	91	824788A	DRIVESHAFT BEARING TOOL	1		
17	91	824790A	DRIVESHAFT BUSHING TOOL	1		
18	91	13658T	MANDREL	1		
19	91	824787	BUSHING REMOVAL TOOL	1		
20	91	824785T	BEARING CARRIER BUSHING/SE	1		
21	91	29310	PLATE	1		
22		NSS	NOT SOLD SEPARATE, Expanding	1		
23		NSS	NOT SOLD SEPARATE, Collet (Jaw	1		
24		FT8950	TESTER KIT	1		