



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1134	3197A 1	END CAP ASSEMBLY, UPPER	1	
2	26	29476	OIL SEAL, END CAP	1	
3	25	47254	"O" RING	1	4
4	15	47248A 1	SHIM, END CAP TO CRANKCASE	AR	
5	10	30225	SCREW, END CAP MOUNTING	4	
6	852	3884A 3	CYLINDER BLOCK AND CRANKC.	1	
7	27	53862	GASKET, CRANKCASE TO CYLI	2	4
8		57854	RESTRICTION, CRANKCASE BL	5	
9	16	35099	STUD, CARBURETOR MOUNTI	6	
10	16	26133	STUD, CRANKCASE TO DRIVE	2	
11	17	20033	PIN, DOWEL - CRANKCASE TO	2	
12	17	20323	PIN, DOWEL - CYLINDER BLOC	3	
13	16	26134	STUD, CYLINDER BLOCK TO D	2	
14	16	48770	STUD, CYLINDER BLOCK TO D	4	
15	16	26324	STUD, CYLINDER BLOCK TO D	2	
16		56029	COVER, STARTER MOTOR BR	1	
17	10	26132	SCREW, TOP COVER ATTACHI	1	
17	10	21449	SCREW, TOP COVER ATTACHI	1	
18	11	46793	NUT, COVER SCREW	2	
19		56030	COVER, STARTER MOTOR BR	1	
20	10	33473	SCREW, BOTTOM COVER ATT	1	
20	10	39767	SCREW, BOTTOM COVER ATT	1	
21	11	46793	NUT, COVER SCREW	1	
22	10	33476	SCREW, CRANKCASE TO CYLIN	3	
22	10	32293	SCREW, CRANKCASE TO CYLIN	2	
22	10	21574	SCREW, CRANKCASE TO CYLIN	21	
23	12	22753	WASHER, CRANKCASE TO CYLIN	26	
24	11	46793	NUT, CRANKCASE FASTENING S	26	
25	10	20359	SCREW, CENTER MAIN BEARIN	2	
26	14	20091	TAB WASHER, BEARING LOCKIN	2	
27	1126	3196A 3	END CAP ASSEMBLY, LOWER	1	
28	21	56011A 1	CHECK VALVE ASSEMBLY, ENC	1	
29	26	29476	OIL SEAL, END CAP	2	
30	25	20081	"O" RING, END CAP	1	4
31	15	20085A 1	SHIM, END CAP TO CRANKCASE	AR	
32	10	30225	SCREW, END CAP MOUNTING (1	3	
33		55200	COVER, WATER JACKET - CYLIN	1	
34	27	47228	GASKET, WATER JACKET COVE	1	4
35	10	53167	SCREW, WATER JACKET COVE	23	
36	13	53166	LOCKWASHER, WATER JACKET	23	
37	27	56382	GASKET, CYLINDER BLOCK TO	1	4