



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	19	45307	PLUG, FLYWHEEL PULLER THRE	1		
2	11	52901	NUT, FLYWHEEL (PART OF A-43)	1		
3	12	33001	WASHER, FLYWHEEL NUT	1		
4	225	2494A14	FLYWHEEL ASSEMBLY, COMPLE	1		
5	10	32417	SCREW, FLEXIBLE PLATE TO F	8		
6	10	49006	SCREW, PLATE AND HUB TO F	8		
7	17	26618	PIN, DOWEL - PULLEY TO FLY	1		
8		29788	FLANGE, FLYWHEEL PULLEY	1		
9		30306	PULLEY, FLYWHEEL	1		
10		29787	HUB, FLYWHEEL PULLEY	1		
11	398	3587	STATOR, ALTERNATOR	1		
12		30050	TERMINAL, STATOR LEAD WIF	2		
13	10	57021	SCREW, STATOR TO UPPER EN	4		
14	54	22875	CLIP, STATOR LEAD FASTENING	2		
14	54	26550	CLIP, STATOR/WIRING HARNES	1		
15	10	30663	SCREW, STATOR LEAD CLIP FA	3		
16		22789	"D" WASHER, CLIP FASTENING :	3		