



12020

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1647	9148A47	GEAR HOUSING (BASIC) (BLACK)	1	
1	1647	9148A48	GEAR HOUSING (BASIC) (GRAY)	1	
47		78956	SHIFT CAM	1	
48		89594A 1	FOLLOWER	1	
49		79911 1	ROD	1	
50	24	79910	SPRING	2	
51	12	78910	WASHER	AR	
52	17	78906	PIN	1	
53		14469	BEARING CUP	1	
54	30	88957A 1	BEARING	1	
55		N.S.S.	Not Sold Seperate, Reverse Gear	1	
56	31	15844	BEARING ASSEMBLY, Roller	1	
57	17	78909	PIN, Detent	2	
58	52	823174	CLUTCH	1	
59	17	78905	PIN, Cross	1	
60	24	78962	SPRING	2	
61	43	18572A 1	FORWARD GEAR (135/150)	1	
61	43	18475A 1	FORWARD GEAR (175/200)	1	
62	23	17615 1	SPACER SHIM, (.125 Inch)	AR	
62	23	17615 2	SPACER SHIM, (.127 Inch)	AR	
62	23	17615 3	SPACER SHIM, (.129 Inch)	AR	
62	23	17615 4	SPACER SHIM, (.131 Inch)	AR	
62	23	17615 5	SPACER SHIM, (.133 Inch)	AR	
62	23	17615 6	SPACER SHIM, (.135 Inch)	AR	
62	23	17615 7	SPACER SHIM, (.137 Inch)	AR	
62	23	17615 8	SPACER SHIM, (.139 Inch)	AR	
62	23	17615 9	SPACER SHIM, (.141 Inch)	AR	
62	23	17615 10	SPACER SHIM, (.143 Inch)	AR	
62	23	17615 11	SPACER SHIM, (.145 Inch)	AR	
62	23	17615 12	SPACER SHIM, (.147 Inch)	AR	
62	23	17615 13	SPACER SHIM, (.149 Inch)	AR	
63	31	15841	ROLLER BEARING	1	
64	12	17616	THRUST RING	1	
65	25	31534	O-RING	1	2,15
66		18447A 2	BEARING ADAPTOR	1	
67	31	15843	ROLLER BEARING	1	
68	12	18448	THRUST WASHER	2	
69	31	15842	BEARING, Thrust	2	
70	44	18446	PROPELLER SHAFT	1	
71		818896A 2	BEARING CARRIER	1	
72	21	20956	BEARING, Needle	1	