



1350

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
0	1647	9148T86	GEAR HOUSING ASSEMBLY, Con	1	[X-LONG - 1.87:1]	
0	1647	9148T83	GEAR HOUSING ASSEMBLY, Con	1	[X-LONG - 2:1]	
1	1647	9148T93	GEAR HOUSING, (Basic)	1		
2		89594A 1	FOLLOWER	1		24
3		78956 2	SHIFT CAM	1		24
4		828287	ROD	1		24
5	15	44491A 1	SHIM SET	AR		23
6		828830A 2	BEARING ADAPTOR ASSEMBL	1		
7	31	814653T	ROLLER BEARING	1		23
8	12	815481	THRUST WASHER,	1		23
9	31	815480	BEARING, Thrust	1		23
10	43	828702A 2	REVERSE GEAR, (15/28)	1	(1.87:1 Gear Ratio)	
10	43	828704A 2	REVERSE GEAR, (14/28)	1	(2:1 Gear Ratio)	
11	31	15844	BEARING ASSEMBLY, Roller	1		23
12	24	30893	SPRING	1		24
13	52	859340T	CLUTCH	1		24
14	17	30632	PIN, Cross	1		24
15	17	828356	PIN, Detent	1		24
16	44	828951	PROPELLER SHAFT	1		
17	43	828701A 1	FORWARD GEAR, (15/28)	1	(1.87:1 Gear Ratio)	22
17	43	828703A 1	FORWARD GEAR, (14/28)	1	(2:1 Gear Ratio)	22
18	23	17615 52	SPACER SHIM, (.202)	AR		
18	23	17615 53	SPACER SHIM, (.204)	AR		
18	23	17615 14	SPACER SHIM, (.206)	AR		
18	23	17615 15	SPACER SHIM, (.208)	AR		
18	23	17615 16	SPACER SHIM, (.210)	AR		
18	23	17615 17	SPACER SHIM, (.212)	AR		
18	23	17615 18	SPACER SHIM, (.214)	AR		
18	23	17615 19	SPACER SHIM, (.216)	AR		
18	23	17615 20	SPACER SHIM, (.218)	AR		
18	23	17615 21	SPACER SHIM, (.220)	AR		
18	23	17615 22	SPACER SHIM, (.222)	AR		
18	23	17615 23	SPACER SHIM, (.224)	AR		
18	23	17615 24	SPACER SHIM, (.226)	AR		
18	23	17615 25	SPACER SHIM, (.228)	AR		
18	23	17615 26	SPACER SHIM, (.230)	AR		
19	31	815480	BEARING, Thrust	1		
20	12	815481	THRUST WASHER,	1		
21		828831A 3	BEARING ADAPTOR ASSEMBL	1		
22	31	814653T	ROLLER BEARING	1		
22	12	18448	THRUST WASHER	2		