



| | | | | Parts List | | |
|-----|-------|----------|------------------------------|------------|----------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 852 | 7739A 3 | CYLINDER BLOCK AND CRANKC | 1 | | |
| 2 | 27 | 53862 | GASKET, CRANKCASE TO CYLI | 2 | | 4 |
| 3 | | 66517 | RESTRICTION, CRANKCASE BL | 5 | | |
| 4 | 16 | 64280 | STUD, CARBURETOR MOUNTI | 6 | | |
| 5 | 16 | 64281 | STUD | 2 | CRANKCASE TO EXHAUST EXT | |
| 6 | 17 | 20033 | PIN, DOWEL - CRANKCASE TO | 2 | | |
| 7 | 17 | 63779 | PIN, DOWEL - CYLINDER BLOC | 3 | | |
| 8 | 16 | 64282 | STUD | 6 | CYLINDER BLOCK TO DRIVE SH | |
| 9 | | 86473 | COVER, STARTER MOTOR BR/ | 1 | | |
| 10 | 10 | 69268 | SCREW, TOP COVER ATTACHI | 2 | | |
| 11 | 13 | 26993 | LOCKWASHER, TOP COVER SC | 1 | | |
| 13 | | 76867 | COVER, STARTER MOTOR BR/ | 1 | | |
| 14 | 10 | 69268 | SCREW, BOTTOM COVER ATT, | 2 | | |
| 15 | 13 | 26993 | LOCKWASHER, BOTTOM COVE | 2 | | |
| 17 | 10 | 57841 | SCREW, CRANKCASE TO CYLINI | 3 | | |
| 17 | 10 | 32293 | SCREW, CRANKCASE TO CYLINI | 3 | | |
| 17 | 10 | 73657 | SCREW, CRANKCASE TO CYLINI | 20 | | |
| 17 | 10 | 53016 | SCREW, CRANKCASE TO CYLINI | 2 | | |
| 18 | 12 | 22753 | WASHER | 25 | CRANKCASE TO CYLINDER BLC | |
| 19 | 11 | 29250 | NUT | 2 | CRANKCASE TO CYLINDER BLC | |
| 20 | 10 | 20359 | SCREW, CENTER MAIN BEARING | 2 | | |
| 21 | 14 | 20091 | TAB WASHER, BEARING LOCKIN | 2 | | |
| 25 | 21 | 77560 | CHECK VALVE, BLEED HOSE - UF | 1 | | |
| 26 | 32 | 54935 76 | HOSE, BLEED (22") | 1 | | |
| 27 | 21 | 77561 | CHECK VALVE, BLEED HOSE - LC | 1 | | |
| 28 | 22 | 25885 | ELBOW, BALANCE HOSE | 2 | | |
| 29 | 32 | 34395A 1 | HOSE, BALANCE - MAIN BEARING | 2 | | |
| 30 | 22 | 85578 | TEE, BALANCE HOSE | 1 | | |
| - | 27 | 85653A79 | GASKET SET | | | |