



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		76509A 3	TRIM CYLINDER ASSEMBLY	2		
2	22	74036	GREASE FITTING, TRIM CYLIND	2		
3	10	45265	SCREW, BLEED - TRIM CYLIND	4		
4	25	45016	"O" RING, TRIM CYLINDER BLE	4		
5	10	45264	SCREW	2	TRIM CYLINDER TO LOWER SH	
6	12	28421	WASHER, TRIM CYLINDER BOLT	4		
7	23	45280	SPACER, TRIM CYLINDER - LOW	2		
8	23	45281	BUSHING, RUBBER - TRIM CYLIN	2		
9		89108A 3	BRACKET, MOUNTING - TRIM CY	1		
10	26	70608	OIL SEAL, PORT MOUNTING BF	1		
11		89290	PLUNGER, LIMIT SWITCH ACTUA	1		
12	24	45272	SPRING, TENSION - LIMIT SWITC	1		
13	16	45282	STUD	1	MOUNTING BRACKET AND TRA	
14	13	26993	LOCKWASHER	2	MOUNTING BRACKET TO TRAN	
15	11	28770	NUT	2	MOUNTING BRACKET TO TRAN	
16	10	45263	SCREW	2	MOUNTING BRACKET TO UPPE	
17	10	68298	BOLT	6	MOUNTING BRACKET TO BOAT	
17	10	89673	BOLT	2	MOUNTING BRACKET TO BOAT	
18	12	68410	WASHER, MOUNTING BRACKET	6		
19	11	68411	NUT, MOUNTING BRACKET BOL	8		
20		89111	BRACKET	1	MOUNTING - TRIM CYLINDER (S	
21	10	45328	SCREW	2	TRIM CYLINDER TO MOUNTING	
22	12	37807	WASHER	1	TRIM CYLINDER SCREW (STAR	
23	11	20696	NUT, TRIM CYLINDER SCREW	2		
24	24	24390	SPRING, TENSION - ADJUSTING	1		
25	16	21085	STUD, ADJUSTING - CUT-OUT LI	1		
26	11	45812	NUT, JAM - LIMIT SWITCH ADJU	1		
27		45508	CAM, LIMIT SWITCH ADJUSTING	1		
28		86967	PLATE, RETAINING - LIMIT SWIT	1		
29	10	68513	SCREW	1	RETAINING PLATE AND CAM TO	
30	13	26996	LOCKWASHER	1	RETAINING PLATE AND CAM S	
31		45326A 2	SWITCH ASSEMBLY, CUT-OUT L	1		
32	23	45354	BUSHING, RUBBER - CUT-OUT L	1		
33	10	47255	SCREW	2	CUT-OUT LIMIT SWITCH TO MO	
34		89272	COVER, LIMIT SWITCH	1		
35	27	89273	GASKET, LIMIT SWITCH COVER	1		
36	10	34994	SCREW	4	LIMIT SWITCH COVER TO MOU	
37	12	38833	WASHER, LIMIT SWITCH COVER	4		
38		87774A 1	COVER, INLET - TRANSOM	1		
39	27	87775	GASKET, INLET COVER	1		
40	25	45507	GROMMET, RUBBER, INLET COV	1		