

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	332	4895A 2	IGNITION COIL ASSEMBLY	1		
2		63194	PAD, RUBBER - IGNITION COIL	1		
3		63195	COVER, IGNITION COIL	1		
4	10	69046	SCREW, COIL TO CYLINDER BLC	3		
5	12	30164	WASHER, COIL SCREW	3		
6	84	60466A 1	CABLE ASSEMBLY	1		
7	11	45076	NUT, IGNITION COIL TERMINAL	2		
8	84	66054A 2	CABLE ASSEMBLY, COIL TO SWI	1		
9	10	62568	SCREW	1	IGNITION COIL WIRE TO SWITC	
10		69190	PLATE, COIL MOUNTING	1		

