



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1	1440	3291A	CLAMP BRACKET ASSEMBLY	2			
2		28403A	THUMB SCREW ASSEMBLY	2			
3	12	28404	WASHER, THUMB SCREW	2			
4		30664	TUBE, TILT - CLAMP BRACKET T	1			
5	12	52864	WASHER, CLAMP BRACKET TILT	2			
6	11	56041	NUT, TILT TUBE FASTENING	2			
7		53078	CAP, PLASTIC - TILT TUBE	2			
8	23	59624	SPACER, CLAMP BRACKET STUC	1			
9	16	59625	STUD, CLAMP BRACKET (NOT U:	1			
10	13	26993	LOCKWASHER, CLAMP BRACKET	2			
11	11	28770	NUT, CLAMP BRACKET STUD	2			
12	17	49930A	TILT LOCK PIN ASSEMBLY	1			
14	1453	4886A	SWIVEL BRACKET ASSEMBLY (S	1			
14	1447	4885A	SWIVEL BRACKET ASSEMBLY (L	1			
15	26	37448	OIL SEAL, SWIVEL BRACKET	2			
16	10	47828	SCREW, DRIVE - SWIVEL BRAC	1			
17	22	23612	FITTING, GREASE - SWIVEL BF	1			
18		29359	LUBRICAP, SWIVEL BRACKET GF	1			
19	24	28659	SPRING, COIL - SWIVEL BRACK	1			
20	17	38311	PIN, COIL SPRING MOUNTING - N	1			
21		47799A	TILT LOCK ASSEMBLY, STARBO:	1			
22		47800A	TILT LOCK ASSEMBLY, PORT	1			
23		47802	TUBE, TILT LOCK	1			
24	18	47959	COTTER, PIN, TILT LOCK TUBE	2			
25	23	47803	BUSHING< TILT LOCK TUBE	2			
26	13	24850	WASHER, WAVE - TILT LOCK TU	2			
27	17	49841A	SWIVEL PIN AND STEERING ARM	1			
27	17	49840A	SWIVEL PIN AND STEERING ARM	1			
28		28203	BUMPER, STEERING ARM	1			
29	10	49554	BOLT, STEERING ARM TO UPPE	2			
30	11	34933	NUT, STEERING ARM BOLT FAS	2			
31	10	31830	SCREW, RIDE-GUIDE ATTACHIN	1			
32	11	20509	NUT, RIDE-GUIDE ATTACHING S	1			
33	12	37429	WASHER, SWIVEL PIN - LOWER	1			
34		37419	YOKE, BOTTOM	1			
35	11	37424	NUT, SWIVEL PIN RETAINING	1			
36		28205	STRAP STOP, DRIVE SHAFT HOL	1			
37	10	56743	SCREW, STRAP STOP TO DRIVE	1	SHORT SHAFT		
37	10	28200	SCREW, STRAP STOP TO DRIVE	1	LONG SHAFT		
38	11	25269	NUT, STRAP STOP FASTENING	1			
39	22	28688	SPACER, RUBBER, COIL SPRING	2	NOT USED WITH FULL POWER		