



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1134	3197A 1	END CAP ASSEMBLY, UPPER	1		
2	26	29476	OIL SEAL, END CAP	1		
3	25	47254	"O"RING	1		4
4	15	47248A 1	SHIM, END CAP TO CRANKCASE	AR		
5	10	30225	SCREW, END CAP MOUNTING	4		
6	852	4589A 5	CYLINDER BLOCK AND CRANKC.	1	SERIAL 00000000-03295133	
6	852	4880A 3	CYLINDER BLOCK AND CRANKC.	1	SERIAL 03295134-09999999	
7	27	53862	GASKET, CRANKCASE TO CYLI	2		4
8		57854	RESTRICTION, CRANKCASE BL	5		
9	16	35099	STUD, CARBURETOR MOUNTI	6		
10	16	26133	STUD, CRANKCASE TO EXHAU	2		
11	17	20033	PIN, DOWEL - CRANKCASE TO	2		
12	17	20323	PIN, DOWEL - CYLINDER BLOC	3		
14	16	60463	STUD, CYLINDER BLOCK TO D	6		
15		56029	COVER, STARTER MOTOR BR	1		
16	10	26132	SCREW, TOP COVER ATTACHI	1		
16	10	21449	SCREW, TOP COVER ATTACHI	1		
17	12	22753	WASHER, TOP COVER ATTACH	2		
18	11	46793	NUT, COVER SCREW	2		
19		56030	COVER, STARTER MOTOR BR	1		
20	10	33473	SCREW, BOTTOM COVER ATT	1		
20	10	39767	SCREW, BOTTOM COVER ATT	1		
21	12	22753	WASHER, BOTTOM COVER AT	2		
22	11	46793	NUT, COVER SCREW	1		
23	10	33473	SCREW, CRANKCASE TO CYLIN	3		
23	10	32293	SCREW, CRANKCASE TO CYLIN	2		
23	10	21574	SCREW, CRANKCASE TO CYLIN	21		
24	12	22753	WASHER, CRANKCASE TO CYLI	26		
25	11	46793	NUT, CRANKCASE FASTENING S	26		
26	10	20359	SCREW, CENTER MAIN BEARIN	2		
27	14	20091	TAB WASHER, BEARING LOCKIN	2		
28	1148	4594A 1	END CAP ASSEMBLY, LOWER	1		
29	21	56011A 1	CHECK VALVE ASSEMBLY, ENC	1		
30	26	29476	OIL SEAL, END CAP	2		
31	25	32546	"O" RING, END CAP	1		4
32	15	20085A 1	SHIM, END CAP TO CRANKCASE	AR		
33	10	30225	SCREW, END CAP MOUNTING (1	3		
34		60436	COVER, WATER JACKET - CYLIN	1		
35	27	60475	GASKET, WATER JACKET COVER	1		4
36	10	53167	SCREW, WATER JACKET COVER	23		
37	12	53165	LOCK WASHER, WATER JACKET	23		