



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	19	45907	PLUG, FLYWHEEL PULLER THRU	1		
2	11	52901	NUT, FLYWHEEL (PART OF A-43)	1		
3	12	33001	WASHER, FLYWHEEL NUT	1		
4	225	2494A14	FLYWHEEL ASSEMBLY, COMPLETE	1		
5	10	32417	SCREW, FLEXIBLE PLATE TO FLY	8		
6	10	49006	SCREW, PLATE AND HUB TO FLY	8		
7	17	26618	PIN, DOWEL - PULLEY TO FLY	1		
8		29788	FLANGE, FLYWHEEL PULLEY	1		
9		20306	PULLEY, FLYWHEEL	1		
10		29787	HUB, FLYWHEEL PULLEY	1		
11	398	4793	STATOR, ALTERNATOR	1		
12		30050	TERMINAL, STATOR LEAD W/IRING	2		
13	10	63136	SCREW, STATOR TO UPPER END	4		
14	54	22875	CLIP, STATOR LEAD FASTENING	2		
14	54	26550	CLIP, STATOR WIRING HARNESS	1		
15	10	30663	SCREW, STATOR LEAD CLIP FASTENING	3		
16		22789	"D" WASHER, CLIP FASTENING	3		