



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		55156A	FUEL PUMP ASSEMBLY	2		
2	21	30430A	CHECK VALVE ASSEMBLY	2		
3		55278A	DIAPHRAGM KIT	2		4
4			GASKET, FUEL PUMP	4		4
5			GASKET, CHECK VALVE TO	4		4
6		23004	RETAINER, CHECK VALVE	2		
7	10	20037	SCREW, RETAINER TO HOUSIII	4		
8	10	27281	SCREW, FUEL PUMP MOUNTING	6		
9	22	32802	PLUG, PIPE - BOTTOM PUMP	1		
10	32	33154A	FUEL LINE ASSEMBLY, PUMP TC	1		
11	22	30174	ELBOW, UPPER CARBURETOR S	1		
12	22	30175	SLEEVE, CARBURETOR STRAINI	1		
13	22	30177	NUT, UPPER CARBURETOR STF	1		
14	54	22627	CLIP, FUEL LINE TO CYLINDER B	2		
15	10	30663	SCREW, FUEL LINE CLIP TO CYL	2		
16		22789	"D" WASHER, FUEL LINE CLIP SI	2		
17	22	29085	ELBOW, FUEL LINE TO CARBURI	2		
18	32	31584A	FUEL LINE ASSEMBLY, CARBURI	2		
19	32	52944A	FUEL LINE ASSY, PUMP TO CAR	1	SERIAL 00000000-03295133	
19	32	55827A	FUEL LINE ASSY, PUMP TO CAR	1	SERIAL 03295134-09999999	
20	32	55828A	FUEL LINE ASSY, PUMP TO PUM	1		
21	22	30468	FITTING, TOP AND BOTTOM PUM	2		
22	22	30175	SLEEVE, TOP AND BOTTOM PUM	2		
23	22	30177	NUT, TOP AND BOTTOM PUMP F	2		
24	32	55829	FUEL LINE, ADAPTOR TO LOWEI	1		
25		30186	ADAPTOR, CHECK UNIT (FUEL LI	1		
26		30187	STEM, CHECK UNIT ADAPTOR	1		
27	24	30189	SPRING, ADAPTOR STEM	1		
28	25	20415	"O" RING, ADAPTOR STEM	1		4
29		30188	CUP WASHER, ADAPTOR	1		
30	10	37990	SCREW, ADAPTOR TO BOTTOM	1		
30	10	31471	SCREW, ADAPTOR TO BOTTOM	1		
31	11	46887	NUT, ADAPTOR FASTENING SCF	2		