



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		45194A 9	TRIM CYLINDER ASSEMBLY	2	
2	10	45265	SCREW, BLEED - SHOCK CYLIN	4	
3	25	45016	"O" RING, SHOCK CYLINDER B	4	
4	10	45264	SCREW, SHOCK CYLINDER TO L	2	
5	23	45280	SPACER, SHOCK CYLINDER - LO	2	
6	23	45281	BUSHING, RUBBER - SHOCK CYL	2	
7		45195	BRACKET, MOUNTING - SHOCK (1	
8	10	45263	SCREW, MOUNTING BRACKET T	2	
9	10	28009	BOLT, MOUNTING BRACKET TO	4	
10	12	28008	WASHER, MOUNTING BRACKET	4	
11	11	28010	NUT, MOUNTING BRACKET BOL	4	
12		45196A 2	BRACKET ASSEMBLY, MOUNTIN	1	
13	26	24590	OIL SEAL, STARBOARD MOUN	1	
14		45286	PLUNGER, LIMIT SWITCH ACTUA	1	
15	24	45272	SPRING, TENSION - LIMIT SWIT	1	
16	16	45282	STUD, MOUNTING BRACKET AN	1	
17	13	26993	LOCKWASHER, MOUNTING BRA	2	
18	11	28770	NUT, MOUNTING BRACKET TO C	2	
19	10	45328	SCREW, SHOCK CYLINDER TO M	2	
20	12	37807	WASHER, SHOCK CYLINDER SCI	1	
21	11	20696	NUT, SHOCK CYLINDER SCREW	2	
22	24	24390	SPRING, TENSION - ADJUSTING	1	
23	16	21085	STUD, ADJUSTING - CUT-OUT LI	1	
24	11	29488	NUT, JAM - LIMIT SWITCH ADJU	1	
25		45508	CAM, LIMIT SWITCH ADJUSTING	1	
26		45509	PLATE, RETAINING - LIMIT SWIT	1	
27	10	31903	SCREW, RETAINING PLATE AND	1	
28	13	26996	LOCKWASHER, RETAINING PLA	1	
29		45326A 2	SWITCH ASSEMBLY, CUT-OUT L	1	
30	23	45354	BUSHING, RUBBER - CUT-OUT	1	
31	10	47255	SCREW, CUT-OUT LIMIT SWITCH	2	
32		45287	COVER, LIMIT SWITCH	1	
33	27	45275	GASKET, LIMIT SWITCH COVER	1	4
34	10	24942	SCREW, LIMIT SWITCH COVER	5	
35		45289	COVER, INLET - TRANSOM	1	
36	27	45274	GASKET, INLET COVER	1	4
37	25	45507	GROMMET, RUBBER - INLET CO	1	
38	10	32866	SCREW, INLET COVER TO BOAT	4	
39	12	20878	WASHER, INLET COVER SCREW	4	
40	11	29488	NUT, INLET COVER SCREW	4	
41	22	45227	HOSE, TRIM CYLINDER TO COA	2	