



16707

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
0	1666	8833T 33	GEAR HOUSING ASSEMBLY, Con	1	(Short)	
0	1666	8833T 35	GEAR HOUSING ASSEMBLY, Con	1	(Long)	
1	1666	8833A17	GEAR HOUSING, Basic	1		
2	31	821321A 1	ROLLER BEARING	1		
3		NSS	NOT SOLD SEPARATE, Cup	1		
4	43	821924A 1	FORWARD GEAR (13-26)	1		
5	23	41367	BUSHING	1		
6		813139	CAM FOLLOWER	1		
7	52	821930A 1	CLUTCH ASSEMBLY	1		
8	17	823951	CROSS PIN	1		
9	24	42204	SPRING	1		
10	44	821929	PROPELLER SHAFT	1		
11	43	821926T 1	REVERSE GEAR, (13-26)	1		
12		42144T 3	BEARING CARRIER	1		
13	25	33145	O-RING, (1.984 x .139)	1		15
14	23	821927	BUSHING	1		
15	26	99325	SEAL	1		15
16	26	821928	OIL SEAL	1		15
17	10	824071 10	SCREW, (M8 x 50)	1		
18	10	824071 7	SCREW, (M8 x 30)	2		
19	48	828156A12	PROPELLER, (9.00 x 9.00)	1		
20	11	40140	NUT, (M10)	1		
21		821932 1	THRUST HUB	1		
22	23	42091 1	SPACER	1		
-	26	41365A 3	SEAL KIT	1		