



3520

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	400	834957A03	CRANKSHAFT	1		5
2	31	834960011	BEARING	4	(Black)	5
2	31	834960012	BEARING	4	(Brown)	5
3	26	855681004	SEAL, Oil	1		5,2
4	26	855681005	SEAL, Oil	1		5,2
5	28	825666001	MAGNETO KEY	1		5
6	28	825666002	KEY	1		
7	600	834961003	ROD, Connecting	2		5
8	10	803509 2	BOLT	4		5
9	41	803521	PISTON PIN	2		5
10	53	16057 3	E RING	4		5
11	700	834963005	PISTON	2	(Standard)	5
11	700	834963006	PISTON	2	(0.5 mm Oversize)	
-	39	803518T01	RING SET, Piston	1	(Standard)	5
-	39	803518T02	RING SET, Piston	AR	(.5 Oversize)	
12	39	803518	PISTON RING, Top	2	(Standard)	5
12	39	803518 1	PISTON RING, Top	2	(0.5 mm Oversize)	
13	39	803519	PISTON RING, Second	2	(Standard)	5
13	39	803519 1	PISTON RING, Second	2	(0.5 mm Oversize)	
14	26	803520	OIL RING	2	(Standard)	5
14	26	803520 1	OIL RING	2	(0.5 mm Oversize)	
-	27	850836A05	GASKET SET, Powerhead	1		
-		895274A05	POWERHEAD ASSEMBLY	1		