



3547

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	1668	803729A09	GEAR HOUSING ASSEMBLY, Con	1	(Short)	
-	1668	803729A10	GEAR HOUSING ASSEMBLY, Con	1	(Long)	
1	1668	803729A 3	GEAR HOUSING	1		
2	30	16132T01	BEARING, Ball	1		
3	43	812944003	FORWARD GEAR	1		
4		803747	PUSH ROD	1		
5		853764	HOLDER	1		
6	24	803746	SPRING	1		
7	52	803745	CLUTCH	1		
8	17	16085 1	PIN	1		
9	24	17667 2	SPRING	1		
10	44	803744	PROPELLER SHAFT	1		
11		803732A 1	BEARING CARRIER	1		
12	25	803735	O-RING	1		15
13	30	16132 1	BALL BEARING	1		
14	31	803734	NEEDLE BEARING	1		
15	26	16162 2	SEAL, Oil	1		15
16	10	825702002	BOLT	2		
17	12	803742	WASHER	1		
18	43	812945004	REVERSE GEAR	1		
19		803743	THRUST HOLDER	1		
20	48	879781A10	PROPELLER, (6 Pitch)	OPT	(6)	
20	48	879779A10	PROPELLER, (7 Pitch)	OPT	(7)	
20	48	879780A10	PROPELLER, (8 Pitch)	OPT	(8)	
20	48	803832A10	PROPELLER, (8.5 Pitch)	OPT	(8.5)	
20	48	853790A10	PROPELLER, (9 Pitch)	1	(9) (Standard Long)	
20	48	815083A10	PROPELLER, (10 Pitch)	1	(10) (Standard Short)	
21	12	16140 2	WASHER	1		
22	11	16147 1	PROP NUT	1		
23	18	815026 4	COTTER PIN	1		
-	27	803728A99	GASKET SET, Lower Unit	1		