



3627

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		895174002	COVER	1		
2	10	823042043	SCREW	1		
3	37	802987001	DECAL, F, N, R	1		
4		853739005	BRACKET	1		
5	10	823042	BOLT	1		
6	25	16823002	GROMMET	1		
7		895176001	BRACKET, Shift Lever	1		
8	10	16705 1	BOLT, (M6 x 20)	2		
9		804892003	THROTTLE DRAM	1		
10		16333	ROD SNAP	1		
11		803574003	THROTTLE ROD	1		
12	10	16705	BOLT	1		
13	12	895118002	WASHER	1		
14	23	95286 8	COLLAR	1		
15		803763004	SHIFT LEVER	1		
16	23	895126001	COLLAR	1		
17	10	823042 30	BOLT	1		
18		892774002	ROD, Shift Lever	1		
19		851862002	SHIFT ARM	1		
20		851865002	SHIFT ARM SHAFT	1		
21		851864	STOPPER	1		
22		851864 1	SHIFT DETENT	1		
23	10	823042 23	BOLT	1		
24		803548001	PLATE	1		
25	10	824832 4	SCREW, (M6 x 16)	3		
26		895131A03	CABLE, Starter	1		
27		853817002	BRACKET	1		
28	87	823037A 2	STOP SWITCH, Lanyard	1		
29		823054	LANYARD	1		
30		853986001	SEAL	1		