



17817

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		850838T02	INTAKE VALVE	2		5
2		850839T02	VALVE, Exhaust	2		5
3	26	822647001	SEAL, Intake (Black)	2		5
4	26	822647002	SEAL, Exhaust (Green)	2		5
5	24	803554 4	SPRING	4		5
6		803598	SEAT	4		5
7		803555	RETAINER	4		5
8	28	803556	COTTER	8		5
9		850841003	ARM, Rocker	4		5
10	10	825046001	ADJUSTING SCREW	4		5
11	11	826150001	ADJUSTING NUT	4		5
12		850842001	ROCKER ARM SHAFT	2		5
13		825451001	COLLAR	3		5
14	24	825452002	SPRING	3		5
15	24	825453001	SPRING	1		5
16	12	895118001	WASHER	1		5
-		895274A06	POWERHEAD ASSEMBLY	1		