


Parts List



Ref	Class	Part	Description	Qty	Comment	Footnote
-		42207A 6	RECOIL STARTER ASSEMBLY	1		
1		42207 2	HOUSING, Starter	1		
2		42690	BUSHING	1		
3	53	818853	RING, Retaining	1		
4	24	86857 1	SPRING	1		
5		42034 50	STARTER PULLEY	1		
6	50	12066A 9	ROPE	1		
7	24	86851	SPRING	2		
8		86850 1	CAM	2		
9	53	86849 1	RING, Retaining	2		
10	24	86852	SPRING	1		
11		86853	CAM	1		
12	10	818838	SCREW	1		
13		90478	PAD	1		
14		19018	REST	1		
15		12674	SUPPORT	1		
16	10	40019111	SCREW, (M5 x 35)	2		
17	23	30977 2	SPACER	4		
18	11	40063 3	NUT, (M5)	2		
19		42171	LEVER (UPPER)	1		
20	12	56681	WASHER, (.203 x .500 x .032)	1		
21		42173	LEVER (LOWER)	1		
22	10	48408	SCREW, (#10-16 x .500)	1		
23	10	40011128	SCREW, (M6 x 20)	3		
24		85174A 1	HANDLE ASSEMBLY	1		
25	16	816194 5	STUD, (M6 x 32)	3	SEAPRO/MARATHON MODELS	
26	11	826833 6	NUT, (M6)	3	SEAPRO/MARATHON MODELS	