



## Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	1392	9503A11	CARBURETOR (6)(WMC-20B)	1		
1	1392	9266A12	CARBURETOR (8)(WMC-18B)	1		
1	1392	8846A14	CARBURETOR (9.9)(WMC-23)	1		
2	1395	9473	THROTTLE VALVE	1		
2		815133	THROTTLE VALVE (WMC-23)	1		
3	195	9472	THROTTLE SHAFT (WMC-17/18)	1		
3	1395	9698	SHAFT (WMC-17C/18A/18B/20A)	1		
3		813022	SHAFT (WMC-23)(INCL.SCREW)	1		
4	1395	9164	FUEL BOWL	1		
5	1395	9169	FLOAT	1		
6	1395	9855	INLET NEEDLE VALVE	1		
7	1399	5315	MAIN FUEL JET (.042)(6)	1		
7	1399	5317	MAIN FUEL JET (.046)(8)	1		
7	1399	5213	MAIN FUEL JET (.056)(9.9)	1		
7	1395	6359	MAIN FUEL JET (.052)(9.9)	1		
8	1395	9171	PLUG, JET RETAINER	1		
9		813618	COVER, DIAPHRAGM	1		
10	1395	9174	SCREW (WMC-17/18/20)	4		
10	1395	9697	SCREW (WMC-17B/17C/18A/18B)	4		
11		15827A	FUEL PUMP KIT	1		
12	1395	9643	SCREW, FUEL PUMP COVER	5		
13	1395	9177	PLATE (WMC-17/18/20)	1		
13	1395	9699	PLATE (WMC-17B/17C/18A/18B)	1		
14	1395	9172	SCREW (WMC-17/18/20)	2		
14	1395	9696	SCREW (WMC-17B/17C/18A/18B)	2		
15	1395	9725	GASKET/DIAPHRAGM KIT	1		
16	1395	9648	REPAIR PARTS KIT	1		
16		813023	REPAIR PARTS KIT(WMC-23)	1		
17	1395	9637	COVER, FUEL PUMP	1		
18	1395	9762	PLUG	1		
19	27	19206	GASKET, CARBURETOR	1		2
19A	1395	9635	DIAPHRAGM	1		
20		44554	IDLE WIRE	1		
21		12805	FAST IDLE LEVER	1		
22		12803	PRIMER BRACKET	1		
23	11	97877	PUSHNUT	1		
24	10	79964	SCREW	1		
25	24	11277	SPRING	1		
26	10	40056110	SCREW(M5X 8X 30)	2		
26	10	40001	SCREW(M5X 8X 12)	2		
27	10	79965	SCREW	1		