



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		45194A18	TRIM CYLINDER ASSEMBLY	2	SEE PAGE 49 FOR REPAIR KIT E	
1A		76509A 3	TRIM CYLINDER ASSEMBLY	2	SEE PAGE 49 FOR REPAIR KIT E	
1A	22	74036	FITTING, GREASE	2	SEE PAGE 49 FOR REPAIR KIT E	
2	10	45265	SCREW, BLEED - SHOCK CYLIN	4		
3	25	45016	"O" RING, SHOCK CYLINDER B	4		
4	10	45264	SCREW, SHOCK CYLINDER TO L	2		
5	23	45280	SPACER, SHOCK CYLINDER - LO'	2		
6	23	45281	BUSHING, RUBBER - SHOCK CYL	2		
7		66084	BRACKET, MOUNTING - SHOCK (1		
8	10	45263	SCREW, MOUNTING BRACKET T	2		
9	10	68298	BOLT, MOUNTING BRACKET TO	6		
10	12	68410	WASHER, MOUNTING BRACKET	6		
11	11	68411	NUT, MOUNTING BRACKET BOL	6		
12		45196A 2	BRACKET ASSEMBLY, MOUNTIN	1		
13	26	70608	OIL SEAL, STARBOARD MOUN	1		
14		45286	PLUNGER, LIMIT SWITCH ACTUA	1		
15	24	45272	SPRING, TENSION - LIMIT SWIT	1		
16	16	45282	STUD, MOUNTING BRACKET AN	1		
17	13	26993	LOCKWASHER, MOUNTING BRA	2		
18	11	28770	NUT, MOUNTING BRACKET TO C	2		
19	10	45328	SCREW, SHOCK CYLINDER TO M	2		
20	12	37807	WASHER, SHOCK CYLINDER SCI	1		
21	11	20696	NUT, SHOCK CYLINDER SCREW	2		
22	24	24390	SPRING, TENSION - ADJUSTING	1		
23	16	21085	STUD, ADJUSTING - CUT-OUT LI	1		
24	11	45812	NUT, JAM - LIMIT SWITCH ADJU	1		
25		45508	CAM, LIMIT SWITCH ADJUSTING	1		
26		45509	PLATE, RETAINING - LIMIT SWIT	1		
27	10	68513	SCREW, RETAINING PLATE AND	1		
28	13	26996	LOCKWASHER, RETAINING PLA	1		
29		45326A 2	SWITCH ASSEMBLY, CUT-OUT L	1		
30	23	45354	BUSHING, RUBBER - CUT-OUT	1		
31	10	47255	SCREW, CUT-OUT LIMIT SWITCH	2		
32		45287	COVER, LIMIT SWITCH	1		
33	27	45275	GASKET, LIMIT SWITCH COVER	1		
34	10	24942	SCREW, LIMIT SWITCH COVER	5		
35		45289	COVER, INLET - TRANSOM	1		
36	27	45274	GASKET, INLET COVER	1		
37	25	45507	GROMMET, RUBBER - INLET CO	1		
38	10	32866	SCREW, INLET COVER TO BOAT	4		
39	12	20878	WASHER, INLET COVER SCREW	4		