





1		Parts List						
п	Ref	Class	Part	Description	Qty	Comment	Footnote	
ı	1	332	2983A 5	IGNITION COIL ASSEMBLY, COMI	1	UNITED STATES 4121434 AND I		
п	2	10	37941	SCREW, COIL MOUNTING BRACK	1	UNITED STATES 4121434 AND I		
ı	3	13	26992	LOCKWAHSER, COIL MOUNTING	1	UNITED STATES 4121434 AND I		
ı	4	10	31471	SCREW, COIL MOUNTING BRACK	2	UNITED STATES 4121434 AND I		
ı	5	23	52933	SPACER, COIL BRACKET TO BOT	3	UNITED STATES 4121434 AND I		
ı	6	11	46887	NUT, COIL MOUNTING BRACKET	2	UNITED STATES 4121434 AND I		
ı	7	332	4895A 2	IGNITION COIL ASSEMBLY	1	UNITED STATES 4121435 AND I		
ı	8		63194	PAD, RUBBER - IGNITION COIL	1	UNITED STATES 4121435 AND I		
ı	9		63195	COVER, IGNITION COIL	1	UNITED STATES 4121435 AND I		
ı	10	10	69046	SCREW, COIL TO CYLINDER BLC	3	UNITED STATES 4121435 AND I		
ı	11	12	30164	WASHER, COIL SCREW	2	UNITED STATES 4121435 AND I		
ı	12	84	60466A 1	CABLE ASSEMBLY	1	UNITED STATES 4121435 AND I		
ı	13	13	26996	LOCKWASHER, IGNITION COIL T	2	UNITED STATES 4121435 AND I		
ı	14	11	45076	NUT, IGNITION COIL TERMINAL I	2	UNITED STATES 4121435 AND I		
ı	15	84	66054A 2	CABLE ASSEMBLY, COIL TO SWI	1	UNITED STATES 4121435 AND I		
ı	16	10	62568	SCREW, IGNITION COIL WIRE TO	1	UNITED STATES 4121435 AND I		
ı	17		69190	PLATE, COIL MOUNTING	1	UNITED STATES 4121435 AND I		
ı								