



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1368	5038A 1	CARBURETOR ASSEMBLY (WMK-	3	
2	1399	110A 1	FLOAT ASSEMBLY	3	
3			PIN, FLOAT LEVER PINION	6	3
4			LEVER, FLOAT (LOWER)	3	3
5			LEVER, FLOAT (UPPER)	3	3
6	4395	4868	INLET NEEDLE, SEAT AND GA	3	3
7			GASKET, INLET SEAT	3	0,3
8			GASKET, FLOAT BOWL COVER	3	0,3
9	1399	4559	COVER, FLOAT BOWL	3	
10	10	52195	SCREW, FLOAD BOWL COVER	3	
11	10	52196	SCREW, FLOAD BOWL COVER	3	
12	43	26995	LOCKWASHER, FLOAD BOWL C	6	
13			GASKET, STRAINER COVER (L	3	0,3
14	1399	3938	SCREEN, FILTER	3	3
15			GASKET, STRAINER COVER (S	3	0,3
16	1399	4791	COVER, STRAINER	3	
17			GASKET, STRAINER COVER SC	3	0,3
18	10	25822	SCREW, STRAINER COVER FA	3	3
19	10	20847	SCREW, THROTTLE STOP LEV	3	3
20	1399	97	LEVER, THROTTLE STOP	3	USED ON CENTER AND LOWEF
21	1399	3527	SHAFT, THROTTLE	3	
22			TUBE, IDLE	3	3
23	1395	4540	SCREW, BODY (IDLE TUBE)	3	
24			SCREW AND LOCKWASHER, T	6	3
25	1395	5108	SHUTTER, THROTTLE	3	
26			SPRING, IDLE ADJUSTMENT S	3	3
27	1399	3515	SCREW, IDLE ADJUSTMENT	3	3
28	1395	4541	SCREW, PLUG - MAIN FUEL JE	3	
29			GASKET, JET CHANNEL PLUG	3	0,3
30	1399	3518	JET, MAIN FUEL (.082)	OPT.	
30	1399	3519	JET, MAIN FUEL (.080) - STAND	3	3
30	1399	3520	JET, MAIN FUEL (.0785)	OPT.	
30	1399	3796	JET, MAIN FUEL (.076)	OPT.	
31			NOZZLE, MAIN	3	3
32	1395	4542	SCREW, PLUG - MAIN NOZZLE	3	
33			SPRING, THROTTLE SHAFT RE	3	3
34			WELCH PLUG, BODY CHANNEL	3	3
35	1395	4543	SCREW, BODY CHANNEL	3	
--	1399	3523	GASKET AND PACKAGING SET (3	3
--	1395	5107	REPAIR PARTS KIT (1 PER CARB	3	
36	27	48164	GASKET, CARBURETOR FLANGE	2	4