



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	436	6646A 2	CRANKSHAFT ASSEMBLY	1	
3	30	62567	BEARING, BALL - UPPER	1	
4	30	63742	BEARING, BALL - LOWER	1	
5		54196A 6	CARRIER ASSEMBLY, "O" RING	1	
6		65800	"O" RING, CARRIER	1	4
7	535	5397A 4	CENTER MAIN BEARING ASSEMBLY	2	
8	17	20032	DOWEL PIN, CENTER MAIN BEARING	4	
9	29	52168	BEARING, NEEDLE - OUTER RACE	112	
10		26113	RACE, OUTER (PAIR)	2	
11	53	26933	RING, SNAP - OUTER RACE	2	
12	17	47246	DOWEL PIN, STEPPED	2	
13	10	22968	SCREW, CENTER MAIN BEARING	4	
14	11	46887	NUT, BEARING CLAMPING SCREW	4	
15	540	5266A 4	MAIN BEARING ASSEMBLY, VALVE	3	
16	17	20032	DOWEL PIN, MAIN BEARING	6	
17	10	45775	SCREW, MAIN BEARING CLAMPING	6	
18	11	45774	NUT, MAIN BEARING CLAMPING	6	
19	34	65312A 1	REED SET, MATCHED - MAIN BEARING	3	
20	34	65319	REED STOP, MAIN BEARING	12	
21	10	62204	SCREW, REED STOP MOUNTING	30	
22	11	53153	NUT, REED STOP SCREW	30	
23	745	6637A 3	PISTON AND PISTON PIN ASSEMBLY	6	
24	40	52035	LOCK RING, PISTON PIN	12	
25	39	78816A 12	RING, PISTON	2	
26	622	4850A 3	CONNECTING ROD AND CAP ASSEMBLY	6	
27	31	62596A 1	BEARING ASSEMBLY, CRANK PIN	6	
28	10	54803	SCREW, CONNECTING ROD	12	
29	11	49091	NUT, CONNECTING ROD SCREW	12	
30	29	47270	BEARING, NEEDLE - PISTON PIN	174	
31	12	47247	WASHER, NEEDLE LOCATING	12	