



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	1390	8889A 1	CARBURETOR ASSEMBLY (MAN)	1		
1	1390	8677A 1	CARBURETOR ASSEMBLY (ELEC)	1		
2	1395	9180	THROTTLE VALVE	1		
3	1395	9167	THROTTLE SHAFT	1		
4	1395	9164	FUEL BOWL	1		
5	1395	9169	FLOAT	1		
6	1395	9170	VALVE,INLET NEEDLE	1		
7	1395	6201	JET,MAIN FUEL(.080)	1		
8	1395	9171	PLUG,JET RETAINER	1		
9	1395	9165	COVER,DIAPHRAGM	1		
10	1395	9174	SCREW,DIAPHRAGM COVER	4		
11	1395	9166	COVER,FUEL PUMP	1		
12	1395	9173	SCREW,FUEL PUMP COVER	5		
13	1395	9177	PLATE,COVER(MANUAL)	1		
13	1395	9182	PLATE,COVER(ELECTRIC)	1		
14	1395	9172	SCREW,COVER PLATE	2		
15	1395	9179	GASKET/DIAPHRAGM KIT	1		
16	1395	9178	REPAIR PARTS KIT	1		
17	27	41449	GASKET,CARBURETOR	1		2
19	10	40001 8	SCREW,BRACKET TO CARBURE	2		
20		42515A 1	LEVER ASSEMBLY,FAST IDLE	1		
21		41703	LEVER,PRIMER	1		
22		42872 1	IDLE WIRE	1		
23		11024 1	ACTUATOR,PRIMER	1		