



GEAR HOUSING (DRIVE SHAFT)

Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1653	8157A 7	GEAR HOUSING ASSEMBLY, CO	1	
-	1653	8157A 8	GEAR HOUSING ASSEMBLY, CO	1	
1	1653	8157A 6	GEAR HOUSING ASSEMBLY	1	
2	35	98488	SCREEN, WATER INLET - ST,	1	
2	35	98487	SCREEN, WATER INLET - PO	1	
3	10	40031112	SCREW, SCREEN TO GEAR H	1	
4	11	40026 3	NUT, SCREEN SCREW	1	
5	31	85559	ROLLER BEARING, LOWER (S	1	
6	23	85092	SLEEVE, UPPER ROLLER BE	1	
7	31	85558	ROLLER BEARING, UPPER	1	
8	26	33467	SEAL, GEAR HOUSING	2	4
9	45	98084	DRIVE SHAFT - SHORT SHAFT	1	
9	45	98085	DRIVE SHAFT - LONG SHAFT	1	
10	12	94056	WASHER, THRUT - DRIVE SHAF	AR	6
10		96524	WASHER, THRUST - DRIVE SHA	AR	6
11	31	85560	THRUST BEARING, DRIVE SHAF	1	
12	43	85132	PINION GEAR	1	
13	22	67892	SCREW DRAIN - MAGNETIC	1	
14	12	20260	WASHER, DRAIN AND FILLER SC	2	3,4
15	10	79953	SCREW, GREASE FILLER	1	
16		85562A 1	CAM ASSEMBLY, SHIFT	1	
17	17	85096	DRIVE PIN, SHIFT CAM	1	
18	17	85593	ROLL PIN, SHIFT SHAFT	1	
19	12	29245	WASHER, SHIFT SHAFT	1	
20	24	93007	SPRING, SHIFT SHAFT	1	
21	12	85091	WSHER, SHIFT SHAFT	1	
22	25	85594	"O" RING, SHIFT SHAFT	1	4,5
23	25	35276	"O" RING, SHIFT SHAFT RETAIN	1	4,5
24		93878	RETAINER, SHIFT SHAFT	1	
25		85552	BOOT, SHIFT SHAFT	1	4
26		85126	SHIFT SHAFT - SHORT SHAFT	1	
26		86293	SHIFT SHAFT - LONG SHAFT	1	
27	12	29245	WASHER, SHIFT SHAFT - UPPEF	1	
28	27	85087	GASKET, WATER PUMP	1	4,5,3
29		85083	FACE PLATE	1	3
30	12	86645	WASHER, IMPELLER	2	3,4
31	28	85119	KEY, IMPELLER DRIVE	1	3
32	47	85089	IMPELLER	1	3
33	25	69202	"O" RING, WATER PUMP	1	3,4,5
34	46	99157A 1	WATER PUMP ASSEMBLY	1	3
35	10	40026 5	SCREW, WATER PUMP TO GEAR	4	