



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		87997A 1	THROTTLE CAM (USE WITH BC2	1	
1		96096	THROTTLE CA (USE WITH BC2D	1	
2	10	40001 14	SCREW, THROTTLE CAM TO CR.	1	
3	12	87791	WASHER, THROTTLE CAM SCRE	1	
4	13	69150	WAVE WASHER, THROTTLE CAM	1	
5	23	86968	BUSHING, THROTTLE CAM SCRE	1	
6		92425	DASHPOT	1	
7		93001	BRACKET, DASHPOT	1	
8	11	22053	NUT, DASHPOT TERMINAL	2	
9		98463A 1	THROTTLE ROD	1	
10	11	68219	NUT, LOCK-THROTTLE ROD	1	
11		98465	SOCKET, THROTTLE ROD	2	
12		92730	LEVER, CONTROL	1	
13		98464A 1	TIMING ROD	1	
14		95037	PLATFORM, CONTROL	1	
15	24	89540	SPRING, SPARK ADVANCE	1	
16		95034	LEVER, ACTUATING	1	
17	53	46250	RETAINING RING	1	ACTUATING AND CONTROL LEV
18	10	40057108	SCREW, CONTROL PLATFORM (2	
19	10	40037126	SCREW, CONTROL PLATFORM (1	
20	10	40007128	SCREW, SHIFT LEVER TO PLATF	1	
21	12	95093	WASHER, SHIFT LEVER TO PLA	1	
22		95035	LEVER, SHIFT	1	
23	23	95091	SLEEVE, SHIFT LEVER TO PLATF	1	
24	12	35280	WASHER, SHIFT LEVER SCREW	1	
25	11	40063 4	NUT, SHIFT LEVER SCREW	1	
26	17	95029	PIN, SHIFT LEVER	1	
27	12	71055	WASHER, SHIFT LEVER PIN	1	
28	18	21071	COTTER PIN, SHIFT LEVER PIN	1	
29	17	95784	PIN, ACTUATING LEVER	1	
30	12	71055	WASHER, ACTUATING LEVER PI	1	
31	18	21071	COTTER PIN, ACTUATING LEVEF	1	
32		95025	SHIFT LINK	1	
33	23	96202	BUSHING, NYLON - SHIFT LINK	1	
34	12	89302	WASHER, SHIFT LINK	2	
35	18	21071	COTTER PIN, SHIFT LINK	2	
36		95027A 1	SHIFT SHAFT ASSEMBLY, HORIZ	1	
37		95023	LEVER, SHIFT SHAFT	1	
38	53	95019	RETAINING RING, LEVER TO SH	1	
39	23	60762	BUSHING, SHIFT SHAFT	2	
40		95024	LEVER, SHIFT SHAFT	1	